

# INSTRUCTIONS–PARTS LIST

**VERDER**

ALUMINUM AND STAINLESS STEEL  
**VERDERAIR VA 25**  
**Air-Operated  
Diaphragm Pumps**

**819.4470**

Rev. ZAA  
EN

***For fluid transfer applications. For professional use only.***

8.4 bar MAXIMUM FLUID WORKING PRESSURE

8.4 bar MAXIMUM AIR INPUT PRESSURE

**\*NOTE:** Refer to the Pump Listing on page 22 to determine the Model No. of your pump.


Patent No.  
CN ZL94102643.4  
FR 9408894  
JA 3517270  
US 5,368,452



**Important Safety Instructions**  
Read all warnings and instructions in the manual. Save these instructions.



II 2 GD c IIC T4



**Aluminum Model Shown**

02632B

## Table of Contents

Safety Warnings .....	2
Symbols .....	2
Installation .....	4
Operation .....	10
Maintenance .....	11
Troubleshooting .....	12
Service	
Repairing the Air Valve .....	14
Ball Check Valve Repair .....	16
Diaphragm Repair .....	17
Bearing and Air Gasket Removal .....	20
Pump Listing .....	22
Repair Kit Listing .....	23
Parts .....	24
Torque Sequence .....	28
Dimensions .....	29
Technical Data and Performance Chart .....	30
Customer Services/Guarantee .....	32

## Symbols

### Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

### Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

## Warning



INSTRUCTIONS

### EQUIPMENT MISUSE HAZARD

Equipment misuse can cause the equipment to rupture or malfunction and result in serious injury.

- This equipment is for professional use only.
- Read all instruction manuals, tags, and labels before operating the equipment.
- Use the equipment only for its intended purpose. If you are not sure, call VERDER After Sales Service.
- Do not alter or modify this equipment.
- Check equipment daily. Repair or replace worn or damaged parts immediately.
- Do not exceed the maximum working pressure of the lowest rated component in your system. This equipment has an **8.4 bar maximum working pressure at 8.4 bar maximum incoming air pressure**.
- Use fluids and solvents which are compatible with the equipment wetted parts. Refer to the **Technical Data** section of all equipment manuals. Read the fluid and solvent manufacturer's warnings.
- Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents in pressurized aluminum equipment. Such use could result in a chemical reaction, with the possibility of explosion.
- Do not use hoses to pull equipment.
- Route hoses away from traffic areas, sharp edges, moving parts, and hot surfaces. Do not expose VERDER hoses to temperatures above 82°C or below -40°C.
- Do not lift pressurized equipment.
- Comply with all applicable local, state, and national fire, electrical, and safety regulations.

 **Warning****TOXIC FLUID HAZARD**

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in the eyes or on the skin, inhaled, or swallowed.



- Know the specific hazards of the fluid you are using.
- Store hazardous fluid in an approved container. Dispose of hazardous fluid according to all local, state, and national guidelines.
- Always wear protective eyewear, gloves, clothing, and respirator as recommended by the fluid and solvent manufacturer.
- Pipe and dispose of the exhaust air safely, away from people, animals, and food handling areas. If the diaphragm fails, the fluid is exhausted along with the air. See **Air Exhaust Ventilation** on page 8.

**FIRE AND EXPLOSION HAZARD**

Improper grounding, poor ventilation, open flames, or sparks can cause a hazardous condition and result in a fire or explosion and serious injury.



- Ground the equipment. Refer to **Grounding** on page 4.
- If there is any static sparking or you feel an electric shock while using this equipment, **stop pumping immediately**. Do not use the equipment until you identify and correct the problem.
- Provide fresh air ventilation to avoid the buildup of flammable fumes from solvents or the fluid being sprayed.
- Pipe and dispose of the exhaust air safely, away from all sources of ignition. If the diaphragm fails, the fluid is exhausted along with the air. See **Air Exhaust Ventilation** on page 8.
- Keep the work area free of debris, including solvent, rags, and gasoline.
- Electrically disconnect all equipment in the work area.
- Extinguish all open flames or pilot lights in the work area.
- Do not smoke in the work area.
- Do not turn on or off any light switch in the work area while operating or if fumes are present.
- Do not operate a gasoline engine in the work area.

## Installation

### General Information

1. The Typical Installations shown in Figs. 2–4 are only guides for selecting and installing system components. Contact your VERDER Customer Service for assistance in planning a system to suit your needs.
2. Always use Genuine VERDER Parts and Accessories. Refer to Product Data Sheet 819.4471.
3. Reference numbers and letters in parentheses refer to the callouts in the figures and the parts lists on pages 24–25.

### Warning



#### TOXIC FLUID HAZARD

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in the eyes or on the skin, inhaled, or swallowed.

1. Read **TOXIC FLUID HAZARD** on page 3.
2. Use fluids and solvents which are compatible with the equipment wetted parts. Refer to the **Technical Data** section of all equipment manuals. Read the fluid and solvent manufacturer's warnings.

### Tightening Screws Before First Use

Before using the pump for the first time, check and retorque all external fasteners. See Torque Sequence, page 28. After the first day of operation, retorque the fasteners. Although pump use varies, a general guideline is to retorque fasteners every two months.

### Grounding

### Warning



#### FIRE AND EXPLOSION HAZARD

This pump must be grounded. Before operating the pump, ground the system as explained below. Also, read the section **FIRE AND EXPLOSION HAZARD**, on page 3.



To reduce the risk of static sparking, ground the pump and all other equipment used or located in the pumping area. Check your local electrical code for detailed grounding instructions for your area and type of equipment.

### Ground all of this equipment.

- *Pump:* Connect a ground wire and clamp as shown in Fig. 1. Loosen the grounding screw (W). Insert one end of a 1.5 mm<sup>2</sup> minimum ground wire (Y) behind the grounding screw and tighten the screw securely. Connect the clamp end of the ground wire to a true earth ground. Order Part No. 819.0157 Ground Wire and Clamp.




Fig. 1

02646B

- *Air and fluid hoses:* Use only grounded hoses with a maximum of 150 m combined hose length to ensure grounding continuity.
- *Air compressor:* Follow the manufacturer's recommendations.
- *All solvent pails used when flushing,* according to local code. Use only metal pails, which are conductive. Do not place the pail on a non-conductive surface, such as paper or cardboard, which interrupts the grounding continuity.
- *Fluid supply container:* Follow the local code.

# Installation

## Mountings

### Caution

The pump exhaust air may contain contaminants. Ventilate to a remote area if the contaminants could affect your fluid supply. See **Air Exhaust Ventilation** on page 8.

1. Be sure the mounting surface can support the weight of the pump, hoses, and accessories, as well as the stress caused during operation.
2. For all mountings, be sure the pump is bolted directly to the mounting surface.
3. For ease of operation and service, mount the pump so the air valve cover (2), air inlet, and fluid inlet and outlet ports are easily accessible.
4. Rubber Foot Mounting Kit 819.4333 is available to reduce noise and vibration during operation.

## Air Line

### Warning

A bleed-type master air valve (B) is required in your system to relieve air trapped between this valve and the pump. Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury, including splashing in the eyes or on the skin, injury from moving parts, or contamination from hazardous fluids. See Fig. 3.

1. Install the air line accessories as shown in Figs. 2–4 on pages 6 and 7. Mount these accessories on the wall or on a bracket. Be sure the air line supplying the accessories is grounded.
  - a. Install an air regulator (C) and gauge to control the fluid pressure. The fluid outlet pressure will be the same as the setting of the air regulator.
  - b. Locate one bleed-type master air valve (B) close to the pump and use it to relieve trapped air. See the **Warning** above. Locate the other master air valve (E) upstream from all air line accessories and use it to isolate them during cleaning and repair.

c. The air line filter (F) removes harmful dirt and moisture from the compressed air supply.

2. Install a grounded, flexible air hose (A) between the accessories and the 1/2 npt(f) pump air inlet (N). See Fig. 5. Use a minimum 9.5 mm ID air hose. Screw an air line quick disconnect coupler (D) onto the end of the air hose (A), and screw the mating fitting into the pump air inlet snugly. Do not connect the coupler (D) to the fitting until you are ready to operate the pump.

## Fluid Suction Line

1. Use grounded fluid hoses. The pump fluid inlet (R) is 1 in. bspt. On pumps 810.0191, 810.0192, 810.0193, and 810.0194 the pump fluid inlet is 1 in. npt. See Fig. 5. Screw the fluid fitting into the pump inlet securely.
2. If the fluid inlet pressure to the pump is more than 25% of the outlet working pressure, the ball check valves will not close fast enough, resulting in inefficient pump operation.
3. At inlet fluid pressures greater than 1.05 bar, diaphragm life will be shortened.
4. See the **Technical Data** on page 30 for maximum suction lift (wet and dry).

## Fluid Outlet Line

### Warning

A fluid drain valve (J) is required to relieve pressure in the hose if it is plugged. The drain valve reduces the risk of serious injury, including splashing in the eyes or on the skin, or contamination from hazardous fluids when relieving pressure. Install the valve close to the pump fluid outlet. See Fig. 3.


1. Use grounded fluid hoses (L). The pump fluid outlet (S) is 1 in. bspt. On 810.0191, 810.0192, 810.0193, and 810.0194 the fluid outlet port is 1 in. npt. See Fig. 5. Screw the fluid fitting into the pump outlet securely.
2. Install a fluid drain valve (J) near the fluid outlet. See the **Warning** above, and Figs. 2–4 on pages 6 and 7.
3. Install a shutoff valve (K) in the fluid outlet line.

# Installation

## BUNG-MOUNT TYPICAL INSTALLATION

**KEY FOR FIG. 2**

- A Air Supply Line
- B Bleed-Type Master Air Valve (required for pump)
- C Air Regulator
- D Air Line Quick Disconnect
- E Master Air Valve (for accessories)
- F Air Line Filter
- G Fluid Suction Line
- H Bung Adapter
- J Fluid Drain Valve (required)
- K Fluid Shutoff Valve
- L Fluid Line
- Y Ground Wire (required; see page 4 for installation instructions)




02648B

**Fig. 2**

## FLOOR MOUNT TYPICAL INSTALLATION

**KEY FOR FIG. 3**

- A Air Supply Line
- B Bleed-Type Master Air Valve (required for pump)
- C Air Regulator
- D Air Line Quick Disconnect
- E Master Air Valve (for accessories)
- F Air Line Filter
- G Fluid Suction Line
- J Fluid Drain Valve (required)
- K Fluid Shutoff Valve
- L Fluid Line
- Y Ground Wire (required; see page 4 for installation instructions)



02651B

**Fig. 3**

# Installation

## WALL-MOUNT TYPICAL INSTALLATION

### KEY FOR FIG. 4

- A Air Supply Line
- B Bleed-Type Master Air Valve (required for pump)
- C Air Regulator
- D Air Line Quick Disconnect
- E Master Air Valve (for accessories)
- F Air Line Filter
- G Fluid Suction Line
- J Fluid Drain Valve (required)
- K Fluid Shutoff Valve
- L Fluid Line
- M Wall Mounting Bracket
- Y Ground Wire (required; see page 4 for installation instructions)




Fig. 4

02649B

## Changing the Orientation of the Fluid Inlet and Outlet Ports

**On aluminum pumps,** the fluid inlet and outlet manifolds have threaded ports on both ends. The pump is shipped with a plug installed in one end of each manifold, and the opposite end open. See Fig. 5. To change the orientation of the inlet and/or outlet port, remove the plug from one end of a manifold and install it in the opposite end.

**On stainless steel pumps,** the fluid inlet and outlet manifolds have threaded ports on one end only. The pump is shipped with the ports facing the same direction. To reverse the orientation of the ports:

1. Remove the screws and nuts holding the inlet and/or outlet manifold to the covers.
2. Reverse the manifold and reattach. Install the screws and torque to 14–17 N•m. See **Torque Sequence**, page 28.

### KEY

- N 1/2 npt(f) Air Inlet Port
  - P Muffler; Air Exhaust Port is 3/4 npt(f)
  - R\* 1 in. bspt Fluid Inlet Port
  - S\* 1 in. bspt Fluid Outlet Port
  - 106 Manifold and Cover Screws
  - 3 Air Valve Screws
- 1 Torque to 14–17 N•m. See **Torque Sequence**, page 28.
- 2 Torque to 5.6–6.8 N•m.




Fig. 5

02632B

\* On pumps 810.0191, 810.0192, 810.0193, and 810.0194 the inlet and outlet fluid ports are 1 in. npt threads.

## Installation

### Air Exhaust Ventilation

#### Warning




#### **FIRE AND EXPLOSION HAZARD**

Be sure to read and follow the warnings and precautions regarding **TOXIC FLUID HAZARD**, and **FIRE OR EXPLOSION HAZARD** on page 3, before operating this pump.

Be sure the system is properly ventilated for your type of installation. You must vent the exhaust to a safe place, away from people, animals, food handling areas, and all sources of ignition when pumping flammable or hazardous fluids.

Diaphragm failure will cause the fluid being pumped to exhaust with the air. Place an appropriate container at the end of the air exhaust line to catch the fluid. See Fig. 6.

### VENTING EXHAUST AIR



#### KEY

- A Air Supply Line
- B Bleed-Type Master Air Valve (required for pump)
- C Air Regulator
- D Air Line Quick Disconnect
- E Master Air Valve (for accessories)
- F Air Line Filter
- P Muffler
- T Grounded Air Exhaust Hose
- U Container for Remote Air Exhaust

The air exhaust port is 3/4 npt(f). Do not restrict the air exhaust port. Excessive exhaust restriction can cause erratic pump operation.

To provide a remote exhaust:

1. Remove the muffler (P) from the pump air exhaust port.
2. Install a grounded air exhaust hose (T) and connect the muffler (P) to the other end of the hose. The minimum size for the air exhaust hose is 19 mm ID. If a hose longer than 4.57 m is required, use a larger diameter hose. Avoid sharp bends or kinks in the hose.
3. Place a container (U) at the end of the air exhaust line to catch fluid in case a diaphragm ruptures. See Fig. 6.

Fig. 6

02650



# Installation

## Fluid Pressure Relief Kit

### **⚠ Caution**

Pressure Relief Kit 819.4472 (V) is available for bsp Aluminum Pumps, to prevent overpressurization and rupture of the pump or hose. See Fig. 7. The kit includes instructions.


Thermal expansion of fluid in the outlet line can cause overpressurization. This can occur when using long fluid lines exposed to sunlight or ambient heat, or when pumping from a cool to a warm area (for example, from an underground tank).

Overpressurization can also occur if the **VERDERAIR** pump is being used to feed fluid to a piston pump, and the intake valve of the piston pump does not close, causing fluid to back up in the outlet line.

**KEY**

- \*R 1 in. bspt Optional Fluid Inlet Port
- \*S 1 in. bspt Optional Fluid Outlet Port
- V Pressure Relief Kit

- 1 Install kit between fluid inlet and outlet manifolds.
- 2 Connect fluid inlet line here.
- 3 Connect fluid outlet line here.



**Fig. 7**

02653B

\* On pumps 810.0191, 810.0192, 810.0193, and 810.0194, optional inlet and outlet ports are 1 in. npt threads.

## Operation

### Pressure Relief Procedure

#### Warning

##### PRESSURIZED EQUIPMENT HAZARD

The equipment stays pressurized until pressure is manually relieved. To reduce the risk of serious injury from pressurized fluid, accidental spray from the gun or splashing fluid, follow this procedure whenever you:

- Are instructed to relieve pressure,
- Stop pumping,
- Check, clean or service any system equipment,
- Install or clean fluid nozzles.

1. Shut off the air to the pump.
2. Open the dispensing valve, if used.
3. Open the fluid drain valve to relieve all fluid pressure, having a container ready to catch the drainage.

### Flush the Pump Before First Use

The pump was tested in water. If water could contaminate the fluid you are pumping, flush it thoroughly with a compatible solvent. Follow the steps under **Starting and Adjusting the Pump**.

### Starting and Adjusting the Pump

#### Warning



##### TOXIC FLUID HAZARD

To reduce the risk of serious injury, splashing in the eyes or on the skin, and toxic fluid spills, **never** move or lift a pump under pressure. If dropped, the fluid section may rupture.

Always follow the **Pressure Relief Procedure Warning** above before lifting the pump.

1. Be sure the pump is properly grounded. Refer to **Grounding** on page 4.
2. Check all fittings to be sure they are tight. Be sure to use a compatible liquid thread sealant on all male threads. Tighten the fluid inlet and outlet fittings securely.
3. Place the suction tube (if used) in the fluid to be pumped.

**NOTE:** If the fluid inlet pressure to the pump is more than 25% of the outlet working pressure, the ball check valves will not close fast enough, resulting in inefficient pump operation.

4. Place the end of the fluid hose (L) into an appropriate container.
5. Close the fluid drain valve (J).
6. Close the pump air regulator (C). Open all bleed-type master air valves (B, E).
7. If the fluid hose has a dispensing device, hold it open while continuing with the following step.
8. Slowly open the air regulator (C) until the pump starts to cycle. Allow the pump to cycle slowly until all air is pushed out of the lines and the pump is primed.

*If you are flushing*, run the pump long enough to thoroughly clean the pump and hoses. Close the air regulator. Remove the suction tube from the solvent and place it in the fluid to be pumped.

### Pump Shutdown

#### Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** at left.

At the end of the work shift, relieve the pressure.

# Maintenance

## Lubrication

The air valve is designed to operate unlubricated, however if lubrication is desired, every 500 hours of operation (or monthly) remove the hose from the pump air inlet and add two drops of machine oil to the air inlet.

### Caution

Do not over-lubricate the pump. Oil is exhausted through the muffler, which could contaminate your fluid supply or other equipment. Excessive lubrication can also cause the pump to malfunction.

## Flushing and Storage

### Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

Flush the pump often enough to prevent the fluid you are pumping from drying or freezing in the pump and damaging it. Use a compatible solvent.

Always flush the pump and relieve the pressure before storing it for any length of time.

## Tightening Threaded Connections

Before each use, check all hoses for wear or damage, and replace as necessary. Check to be sure all threaded connections are tight and leak-free. Check fasteners. Tighten or retorque as necessary. Although pump use varies, a general guideline is to retorque fasteners every two months. See **Torque Sequence**, page 28.

## Preventive Maintenance Schedule

Establish a preventive maintenance schedule, based on the pump's service history. This is especially important for prevention of spills or leakage due to diaphragm failure.

# Troubleshooting

## Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Relieve the pressure before checking or servicing the equipment.
2. Check all possible problems and causes before disassembling the pump.

PROBLEM	CAUSE	SOLUTION
Pump cycles at stall or fails to hold pressure at stall.	Worn check valve balls (301), seats (201) or o-rings (202).	Replace. See page 16.
Pump will not cycle, or cycles once and stops.	Air valve is stuck or dirty.	Disassemble and clean air valve. See pages 14–15. Use filtered air.
	Check valve ball (301) severely worn and wedged in seat (201) or manifold (102 or 103).	Replace ball and seat. See page 16.
	Check valve ball (301) is wedged into seat (201), due to overpressurization.	Install Pressure Relief Valve (see page 9).
	Dispensing valve clogged.	Relieve pressure and clear valve.
Pump operates erratically.	Clogged suction line.	Inspect; clear.
	Sticky or leaking balls (301).	Clean or replace. See page 16.
	Diaphragm ruptured.	Replace. See pages 17–19.
	Restricted exhaust.	Remove restriction.
Air bubbles in fluid.	Suction line is loose.	Tighten.
	Diaphragm ruptured.	Replace. See pages 17–19.
	Loose inlet manifold (102), damaged seal between manifold and seat (201), damaged o-rings (202).	Tighten manifold bolts (106) or replace seats (201) or o-rings (202). See page 16.
	Loose diaphragm shaft bolt (107).	Tighten or replace (pages 17–19).
	Damaged o-ring (108).	Replace. See pages 17–19.

# Troubleshooting

<b>PROBLEM</b>	<b>CAUSE</b>	<b>SOLUTION</b>
Fluid in exhaust air.	Diaphragm ruptured.	Replace. See pages 17–19.
	Loose diaphragm shaft bolt (107).	Tighten or replace. See pages 17–19.
	Damaged o-ring (108).	Replace. See pages 17–19.
Pump exhausts excessive air at stall.	Worn air valve block (7†■), o-ring (6†■), plate (8■), pilot block (18), u-cups (10), or pilot pin o-rings (17†■).	Repair or replace. See pages 14–15.
	Worn shaft seals (402).	Replace. See pages 17–19.
Pump leaks air externally.	Air valve cover (2) or air valve cover screws (3) are loose.	Tighten screws. See page 15.
	Air valve gasket (4†■) or air cover gasket (22) is damaged.	Inspect; replace. See pages 14–15, 20–21.
	Air cover screws (25) are loose.	Tighten screws. See pages 20–21.
Pump leaks fluid externally from ball check valves.	Loose manifolds (102, 103), damaged seal between manifold and seat (201), damaged o-rings (202).	Tighten manifold bolts (106) or replace seats (201) or o-rings (202). See page 16.

## Service

### Repairing the Air Valve

#### Tools Required

- Torque wrench
- Torx (T20) screwdriver or 7 mm socket wrench
- Needle-nose pliers
- O-ring pick
- Lithium base grease

**NOTE:** Air Valve Repair Kits 819.4274 (aluminum center housing models) and 819.0249 (sst center housing models) are available. Refer to page 23. Parts included in the kit are marked with a symbol, for example (4†■). Use all the parts in the kit for the best results.

#### Disassembly

### Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Relieve the pressure.
2. With a Torx (T20) screwdriver or 7 mm socket wrench, remove the six screws (3), air valve cover (2), and gasket (4). See Fig. 8.
3. Move the valve carriage (5) to the center position and pull it out of the cavity. Remove the valve block (7†■) and o-ring (6†■) from the carriage. Using a needle-nose pliers, pull the pilot block (18†■) straight up and out of the cavity. See Fig. 9.
4. Pull the two actuator pistons (11) out of the bearings (12). Remove the u-cup packings (10†■) from the pistons. Pull the pilot pins (16) out of the bearings (15). Remove the o-rings (17†■) from the push pins. See Fig. 10.
5. Inspect the valve plate (8■) in place. If damaged, use a Torx (T20) screwdriver or 7 mm socket wrench to remove the three screws (3). Remove the valve plate (8■) and, on aluminum center housing models, remove the seal (9†). See Fig. 11.
6. Inspect the bearings (12, 15) in place. See Fig. 10. The bearings are tapered and, if damaged, must be removed from the outside. This requires disassembly of the fluid section. See page 20.
7. Clean all parts and inspect for wear or damage. Replace as needed. Reassemble as explained on page 15.




Fig. 8

02644B





Fig. 9

04165B

# Service

- 1 ▲ Insert narrow end first.
- 2 ▲ Grease.
- 3 ▲ Install with lips facing narrow end of piston (11).
- 4 ▲ Insert wide end first.




Fig. 10

02643B

- 1 ▲ Rounded side must face down (aluminum center housing models only).
- 2 ▲ Tighten screws until they bottom out on the housing.




Fig. 11

02645

## Reassembly

1. If you replaced the bearings (12, 15), reinstall as explained on page 20. Reassemble the fluid section.
2. On aluminum center housing models, install the valve plate seal (9) into the groove at the bottom of the valve cavity. The rounded side of the seal **must face down** into the groove. See Fig. 11.
3. Install the valve plate (8) in the cavity. On aluminum center housing models, the plate is reversible, so either side can face up. Install the three screws (3), using a Torx (T20) screwdriver or 7 mm socket wrench. Tighten until the screws bottom out on the housing. See Fig. 11.
4. Install an o-ring (17) on each pilot pin (16). Grease the pins and o-rings. Insert the pins into the bearings (15), **narrow** end first. See Fig. 10.
5. Install a u-cup packing (10) on each actuator piston (11), so the lips of the packings face the **narrow** end of the pistons. See Fig. 10.
6. Lubricate the u-cup packings (10) and actuator pistons (11). Insert the actuator pistons in the bearings (12), **wide** end first. Leave the narrow end of the pistons exposed. See Fig. 10.
7. Grease the lower face of the pilot block (18) and install so its tabs snap into the grooves on the ends of the pilot pins (16). See Fig. 9.
8. Grease the o-ring (6) and install it in the valve block (7). Push the block onto the valve carriage (5). Grease the lower face of the valve block. See Fig. 9.
9. Install the valve carriage (5) so its tabs slip into the grooves on the narrow end of the actuator pistons (11). See Fig. 9.
10. Align the valve gasket (4) and cover (2) with the six holes in the center housing (1). Secure with six screws (3), using a Torx (T20) screwdriver or 7 mm socket wrench. Torque to 5.6–6.8 N•m. See Fig. 8.

## Service

### Ball Check Valve Repair

#### Tools Required

- Torque wrench
- 10 mm socket wrench
- O-ring pick

#### Disassembly

**NOTE:** A Fluid Section Repair Kit is available. Refer to page 23 to order the correct kit for your pump. Parts included in the kit are marked with an asterisk, for example (201\*). Use all the parts in the kit for the best results.

**NOTE:** To ensure proper seating of the balls (301), always replace the seats (201) when replacing the balls. Also, on some models, replace the o-rings (202).

### Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Relieve the pressure. Disconnect all hoses.
2. Remove the pump from its mounting.
3. Using a 10 mm socket wrench, remove the four bolts (106) and nuts (114, *used on stainless steel pumps only*) holding the outlet manifold (103) to the fluid covers (101). See Fig. 12.
4. Remove the o-rings (202, *not used on some models*), seats (201), and balls (301) from the manifold (103).
5. Turn the pump over and remove the inlet manifold (102). Remove the o-rings (202, *not used on some models*), seats (201), and balls (301) from the fluid covers (101).

#### Reassembly

1. Clean all parts and inspect for wear or damage. Replace parts as needed.
2. Reassemble in the reverse order, following all notes in Fig. 12. Be sure the ball checks and manifolds are assembled **exactly** as shown. The arrows (A) on the fluid covers (101) **must** point toward the outlet manifold (103).

#### Aluminum Model Shown

- 1 Apply medium-strength (blue) Loctite or equivalent to the threads. Torque to 14–17 N•m. See **Torque Sequence**, page 28.
- 2 Arrow (A) must point toward outlet manifold (103).
- 3 Beveled seating surface must face the ball (301).
- 4 Not used on some models.




Fig. 12

02647B



# Service

## Diaphragm Repair

### Tools Required

- Torque wrench
- 10 mm socket wrench
- 15 mm socket wrench (aluminum models) or 1 in. socket wrench (stainless steel models)
- 19 mm open-end wrench
- O-ring pick
- Lithium-base grease

### Disassembly

**NOTE:** A Fluid Section Repair Kit is available. Refer to page 23 to order the correct kit for your pump. Parts included in the kit are marked with an asterisk, for example (401\*). Use all the parts in the kit for the best results.

### ⚠ Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Relieve the pressure.
2. Remove the manifolds and disassemble the ball check valves as explained on page 16.
3. Using a 10 mm socket wrench, remove the screws (106) holding the fluid covers (101) to the air covers (23). Pull the fluid covers (101) off the pump. See Fig. 13.




Fig. 13

02635B

## Service

4. Loosen but do not remove the diaphragm shaft bolts (107), using a 15 mm socket wrench (1 in. on stainless steel models) on both bolts.
5. Unscrew one bolt from the diaphragm shaft (24) and remove the o-ring (108), fluid side diaphragm plate (105), PTFE diaphragm (403, *used on PTFE models only*), diaphragm (401), and air side diaphragm plate (104). See Fig. 14.
6. Pull the other diaphragm assembly and the diaphragm shaft (24) out of the center housing (1). Hold the shaft flats with a 19 mm open-end wrench, and remove the bolt (107) from the shaft. Disassemble the remaining diaphragm assembly.
7. Inspect the diaphragm shaft (24) for wear or scratches. If it is damaged, inspect the bearings (19) in place. If the bearings are damaged, refer to page 20.
8. Reach into the center housing (1) with an o-ring pick and hook the u-cup packings (402), then pull them out of the housing. This can be done with the bearings (19) in place.
9. Clean all parts and inspect for wear or damage. Replace parts as needed.


### Reassembly

1. Install the shaft u-cup packings (402\*) so the lips face **out** of the housing (1). Lubricate the packings. See Fig. 14.
2. Install the diaphragm assembly on one end of the shaft (24) as follows:
  - a. Install the o-ring (108\*) on the shaft bolt (107).
  - b. Install the fluid side diaphragm plate (105) on the bolt so the rounded side faces the diaphragm (401).

**NOTE:** *On stainless steel pumps only*, the fluid side diaphragm plate (105) is stainless steel. This plate **is not** stamped with its part number. Be sure to install this plate on the fluid side of the diaphragm.


- c. *On PTFE models only*, install the PTFE diaphragm (403\*). Make certain the side marked AIR SIDE faces the center housing (1).
  - d. Install the diaphragm (401\*) on the bolt. Make certain the side marked AIR SIDE faces the center housing (1).
  - e. Install the air side diaphragm plate (104) so the rounded side faces the diaphragm (401). This plate is used on all models, and is stamped with its part number.
  - f. Apply medium-strength (blue) Loctite® or equivalent to the bolt (107) threads. Screw the bolt into the shaft (24) handtight.
3. Grease the length and ends of the diaphragm shaft (24), and slide it through the housing (1).
  4. Assemble the other diaphragm assembly to the shaft as explained in step 2.
  5. Hold one shaft bolt (107) with a wrench and torque the other bolt to 27–34 N•m at 100 rpm maximum.
  6. Align the fluid covers (101) and the center housing (1) so the arrows (A) on the covers face the same direction as the air valve (B). Secure the covers with the screws (106), handtight. See Fig. 13. Using a 10 mm socket wrench, torque the screws oppositely and evenly to 14–17 N•m. See **Torque Sequence**, page 28.
  7. Reassemble the ball check valves and manifolds as explained on page 16.

# Service




02638

**Cutaway View, with Diaphragms in Place**



02637

**Cutaway View, with Diaphragms Removed**



- ▲ 1 Lips face out of housing (1).
- ▲ 2 Rounded side faces diaphragm (401).
- ▲ 3 Air Side must face center housing (1).
- ▲ 4 Grease.
- ▲ 5 Apply medium strength (blue) Loctite® or equivalent. Torque to 27-34 N•m.
- ▲ 6 Used on pumps with PTFE diaphragms only.

Fig. 14

02636B

## Service

### Bearing and Air Gasket Removal

#### Tools Required

- Torque wrench
- 10 mm socket wrench
- Bearing puller
- O-ring pick
- Press, or block and mallet

#### Disassembly

**NOTE:** Do not remove undamaged bearings.

### Warning

To reduce the risk of serious injury whenever you are instructed to relieve pressure, always follow the **Pressure Relief Procedure** on page 10.

1. Relieve the pressure.
2. Remove the manifolds and disassemble the ball check valves as explained on page 16.
3. Remove the fluid covers and diaphragm assemblies as explained on page 17.

**NOTE:** If you are removing only the diaphragm shaft bearing (19), skip step 4.

4. Disassemble the air valve as explained on page 14.
5. Using a 10 mm socket wrench, remove the screws (25) holding the air covers (23) to the center housing (1). See Fig. 15.


6. Remove the air cover gaskets (22). Always replace the gaskets with new ones.
7. Use a bearing puller to remove the diaphragm shaft bearings (19), air valve bearings (12) or pilot pin bearings (15). Do not remove undamaged bearings.
8. If you removed the diaphragm shaft bearings (19) reach into the center housing (1) with an o-ring pick and hook the u-cup packings (402), then pull them out of the housing. Inspect the packings. See Fig. 14.

#### Reassembly

1. If removed, install the shaft u-cup packings (402\*) so the lips face **out** of the housing (1).
2. The bearings (12, 15, and 19) are tapered and can only be installed one way. Insert the bearings into the center housing (1), **tapered end first**. Using a press or a block and rubber mallet, press-fit the bearing so it is flush with the surface of the center housing.
3. Reassemble the air valve as explained on page 15.
4. Align the new air cover gasket (22) so the pilot pin (16) protruding from the center housing (1) fits through the proper hole (H) in the gasket.
5. Align the air cover (23) so the pilot pin (16) fits in the middle hole (M) of the three small holes near the center of the cover. Install the screws (25), handtight. See Fig. 15. Using a 10 mm socket wrench, torque the screws oppositely and evenly to 15–17 N•m.
6. Install the diaphragm assemblies and fluid covers as explained on page 17.
7. Reassemble the ball check valves and manifolds as explained on page 16.

# Service

- 1 Insert bearings tapered end first.
- 2 Press-fit bearings flush with surface of center housing (1).
- 3 Apply medium-strength (blue) Loctite or equivalent to the threads. Torque to 15–17 N•m.



02640

**Detail of Air Valve Bearings**




Fig. 15

02639B

## Pump Listing

### VERDERAIR VA 25 Aluminum and Stainless Steel Pumps, Series B

Your Model No. is marked on the pump's serial plate. The listing of existing VERDERAIR VA 25 pumps is below:

Part No.	Air Section	Fluid Section	Seats	Balls	Diaphragms
810.0228	ALU	ALU	ACE	ACE	BUN
810.0248	ALU	ALU	ACE	BUN	BUN
810.6977	ALU	ALU	ACE	GEO	GEO
810.0255	ALU	ALU	316	TEF	TEF
810.0256	ALU	ALU	316	TEF	HYT
810.0270	ALU	ALU	316	440	TEF
810.0300	ALU	ALU	174	316	TEF
810.0305	ALU	ALU	174	440	TEF
810.0312	ALU	ALU	174	SAN	SAN
810.0326	ALU	ALU	HYT	TEF	HYT
810.0331	ALU	ALU	HYT	ACE	HYT
810.0382	ALU	ALU	SAN	SAN	SAN
810.0429	ALU	ALU	VIT	VIT	VIT
810.0430	ALU	ALU	POL	TEF	TEF
810.6980	ALU	ALU	GEO	GEO	GEO
810.0535	ALU	SST	316	TEF	TEF
810.0563	ALU	SST	316	BUN	BUN
810.0569	ALU	SST	316	VIT	VIT
810.0570	ALU	SST	174	TEF	TEF
810.0611	ALU	SST	HYT	ACE	HYT
810.0616	ALU	SST	HYT	316	HYT
810.0662	ALU	SST	SAN	SAN	SAN
810.0779	ALU	SST	KYN	VIT	VIT
810.6981	ALU	SST	316	GEO	GEO
810.7007	ALU	SST	SST	SST	TEF
810.7010	ALU	ALU	HYT	ACE	HYT
810.0077	ALU	ALU	SST	SST	BUN
810.0078	ALU	ALU	BUN	BUN	BUN
810.0079	ALU	SST	SST	SST	BUN
810.0081	ALU	SST	BUN	BUN	BUN
*810.0191	ALU	ALU	SST	TEF	TEF
*810.0192	ALU	ALU	GEO	GEO	GEO
*810.0193	ALU	ALU	SAN	SAN	SAN
*810.0194	ALU	ALU	SST	SST	SST
810.0085	SST	SST	SST	SST	BUN
810.0086	SST	SST	SST	TEF	TEF
810.0087	SST	SST	SAN	SAN	SAN
810.0088	SST	SST	VIT	VIT	VIT

ACE = Acetal ALU = Aluminum BUN = Buna-N HYT = TPE POL = Polypropylene 316 = 316 sst TEF = PTFE  
 SAN = Santoprene VIT = Fluoroelastomer SST = 316 Stainless Steel 174 = 17-4PH sst KYN = PVDF GEO = Geolast

\*These pumps have 1 in. npt inlet and outlet fluid ports.

### 819.7137 Stainless Steel Air Motor Conversion Kit

Use kit 819.7137 and refer to instruction manual 819.7140 (included with kit) to convert from aluminum air motor to stainless steel air motor.

# Repair Kit Listing

## **VERDERAIR VA 25 Aluminum and Stainless Steel Pumps, Series B**

Repair Kits may only be ordered as kits. To repair the air valve, order **Part No. 819.4274** for aluminum center housing models, or **Part No. 819.0249** for stainless steel center housing models (see page 24). Parts included in the Air Valve Repair Kit are marked with a symbol in the parts list, for example (2†■). The list of existing Repair Kits is below:

<b>Part No.</b>	<b>O-Rings</b>	<b>Seats</b>	<b>Balls</b>	<b>Diaphragms</b>
819.0781	TEF	NUL	NUL	TEF
819.0782	TEF	NUL	NUL	HYT
819.0783	TEF	NUL	NUL	SAN
819.0784	TEF	NUL	NUL	BUN
819.0785	TEF	NUL	NUL	VIT
819.0844	TEF	ACE	ACE	BUN
819.0864	TEF	ACE	BUN	NUL
819.0868	TEF	ACE	BUN	BUN
819.3795	TEF	ACE	GEO	GEO
819.0882	TEF	316	TEF	NUL
819.0883	TEF	316	TEF	TEF
819.0884	TEF	316	TEF	HYT
819.0895	TEF	316	316	TEF
819.0901	TEF	316	440	TEF
819.0906	TEF	316	SAN	NUL
819.0909	TEF	316	SAN	SAN
819.0912	TEF	316	BUN	NUL
819.0916	TEF	316	BUN	BUN
819.0918	TEF	316	VIT	NUL
819.0923	TEF	316	VIT	VIT
819.3796	TEF	316	GEO	GEO
819.0943	TEF	174	316	TEF
819.0949	TEF	174	440	TEF
819.0957	TEF	174	SAN	SAN
819.0984	TEF	HYT	ACE	NUL
819.0986	TEF	HYT	ACE	HYT
819.0992	TEF	HYT	316	HYT
819.1050	TEF	SAN	SAN	NUL
819.1053	TEF	SAN	SAN	SAN
819.1123	TEF	POL	TEF	TEF
819.1156	TEF	POL	BUN	BUN
819.3798	TEF	GEO	GEO	GEO

ACE = Acetal BUN = Buna-N HYT = TPE POL = Polypropylene 316 = 316 sst TEF = PTFE SAN = Santoprene  
 VIT = Fluoroelastomer 174 = 17-4PH sst NUL = Null 440 = 440C sst GEO = Geolast

## Parts

### Air Motor Parts List


Ref. No.	Part No	Description	Qty
1	819.4275	HOUSING, center; aluminum	1
	819.0247	HOUSING, center; stainless steel	1
2	819.4276	COVER, air valve; aluminum	1
	819.7103	COVER, air valve; stainless steel	1
3	819.0221	SCREW, mach, hex flange hd; M5 x 0.8; 12 mm	9
4†■	819.4278	GASKET, cover; Santoprene®	1
5	819.4279	CARRIAGE; aluminum	1
6†■	819.4280	O-RING; nitrile	1
7†■	819.4281	BLOCK, air valve; acetal	1
8■	Alum. 819.4282	PLATE, air valve; sst	1
	SST 819.0248	PLATE, air valve; sst	1
9†	Alum. 819.4283	SEAL, valve plate; buna-N	1
	SST -	-	-
10†■	819.4284	PACKING, u-cup; nitrile	2
11	819.4285	PISTON, actuator; acetal	2
12	819.4286	BEARING, piston; acetal	2
15	819.4287	BEARING, pin; acetal	2
16	819.4288	PIN, pilot; stainless steel	2
17†■	819.4289	O-RING; buna-N	2
18†■	819.4290	BLOCK, pilot; acetal	1
19	819.4291	BEARING, shaft; acetal	2
20	819.0220	SCREW, grounding	1
22	819.4294	GASKET, air cover; foam	2
23	819.4368	COVER, air; aluminum	2
	819.7104	COVER, air; stainless steel	2
24	819.4369	SHAFT, diaphragm; sst	1
25	819.7051	SCREW; M8 x 1.25; 25 mm	12

### Fluid Section Parts List

Fluid Section Material	Ref. No.	Part No	Description	Qty
ALUMINUM	101	819.4473	COVER, fluid; aluminum	2
	102	819.6978	MANIFOLD, inlet; aluminum	1
		819.4474	MANIFOLD, inlet; aluminum, npt (for 810.0191, 810.0192, and 810.0193 only)	1
	103	819.6984	MANIFOLD, outlet; aluminum	1
		819.4475	MANIFOLD, outlet; aluminum, npt (for 810.0191, 810.0192, and 810.0193 only)	1
	104	819.4373	PLATE, air side; aluminum	2
	105	819.4373	PLATE, fluid side; aluminum	2
	106	819.7051	SCREW; M8 x 1.25; 25 mm	24
	107	819.4482	BOLT; M12 x 1.75; 35 mm; sst	2
	108*	819.4304	O-RING; PTFE	2
	110▲	819.6310	LABEL, warning	1
	111	819.4376	MUFFLER	1
	113	819.4272	PLUG; 1 in. bspt; cst	2
		819.4477	PLUG; 1 in. npt; cst (for 810.0191, 810.0192, and 810.0193 only)	2
114	None	Not Used	0	
STAINLESS STEEL	101	819.4478	COVER, fluid; sst	2
	102	819.6982	MANIFOLD, inlet; sst	1
		819.4479	MANIFOLD, inlet; sst, npt (for 810.0194 only)	1
	103	819.6987	MANIFOLD, outlet; sst	1
		819.4480	MANIFOLD, outlet; sst, npt (for 810.0194 only)	1
	104	819.4373	PLATE, air side; aluminum	2
	105	819.4481	PLATE, fluid side; sst	2
	106	819.4297	SCREW; M8 x 1.25; 25 mm	24
	107	819.4482	BOLT; M12 x 1.75; 35 mm; sst	2
	108*	819.4304	O-RING; PTFE	2
	110▲	819.6314	LABEL, warning	1
	111	819.4376	MUFFLER	1
	113	None	Not Used	0
	114	819.4483	NUT, hex; M8 x 1.25; sst	8



# Parts



**Aluminum Model Shown**

- △1 Used on pumps with PTFE diaphragms only.
- △2 Not used on stainless steel pumps.
- △3 Not used on aluminum pumps.
- △4 Not used on all models.

\* These parts are included in the Pump Repair Kit, which may only be purchased as a kit. Refer to the Repair Kit Listing on page 23 to determine the correct kit for your pump.

† These parts are included in Air Valve Repair Kit 819.4274 (aluminum center housing models) which may only be purchased as a kit.

■ These parts are included in Air Valve Repair Kit 819.0249 (sst center housing models), which may only be purchased as a kit.

▲ Replacement Danger and Warning labels, tags and cards are available at no cost.

# Parts

## Seat Parts List

Seat Material	Ref. No.	Part No	Description	Qty
316 S S T	201*	819.4386	SEAT; 316 stainless steel	4
	202*	819.6344	O-RING; PTFE	8
17-4 S S T	201*	819.4388	SEAT; 17-4 stainless steel	4
	202*	819.6344	O-RING; PTFE	8
T P E	201*	819.4389	SEAT; TPE	4
	202*	None	Not Used	0
S A N T O P R E N E	201*	819.6866	SEAT; Santoprene	4
	202*	819.6344	O-RING; PTFE	8
B U N A - N	201*	819.7118	SEAT; Buna-N	4
	202*	NONE	NOT USED	0
FLUO ROEL ASTO MER	201*	819.7134	SEAT; Fluoroelastomer	4
	202*	None	Not Used	0

P O L Y P R O P Y L E N E	201*	819.4392	SEAT; polypropylene	4
	202*	819.6344	O-RING; PTFE	8
P V D F	201*	819.4393	SEAT; PVDF	4
	202*	819.6344	O-RING; PTFE	8
G E O - L A S T	201*	819.7057	SEAT; Geolast	4
	202*	819.6344	O-RING; PTFE	8
A C E T A L	201*	819.6343	SEAT; Acetal	4
	202*	819.6344	O-RING; PTFE	8

## Ball Parts List

Ref. No.	Part No	Description	Qty
301*	819.4394	BALL; PTFE	4
301*	819.4395	BALL; acetal	4
301*	819.4396	BALL; 316 stainless steel	4
301*	819.4397	BALL; 440C stainless steel	4
301*	819.4398	BALL; Santoprene	4
301*	819.7125	BALL; buna-N	4
301*	819.7124	BALL; Fluoroelastomer	4
301*	819.7056	BALL; Geolast	4

## Diaphragm Parts List


Diaphragm Material	Ref. No.	Part No	Description	Qty
P T F E	401*	not sold separately	DIAPHRAGM, backup; polychloroprene (CR)	2
	402*	819.4284	PACKING, u-cup; nitrile	2
	403*	819.4402	DIAPHRAGM; PTFE	2
T P E	401*	819.4401	DIAPHRAGM; TPE	2
	402*	819.4284	PACKING, u-cup; nitrile	2
S A N T O P R E N E	401*	819.4403	DIAPHRAGM; Santoprene	2
	402*	819.4284	PACKING, u-cup; nitrile	2
B U N A - N	401*	819.7130	DIAPHRAGM; buna-N	2
	402*	819.4284	PACKING, u-cup; nitrile	2
F L U O R O E L A S T O M E R	401*	819.7131	DIAPHRAGM; Fluoroelastomer	2
	402*	819.4284	PACKING, u-cup; nitrile	2
G E O L A S T	401*	819.7058	DIAPHRAGM; Geolast	2
	402*	819.4284	PACKING; u-cup; nitrile	2

\* These parts are included in the pump repair kit, purchased separately. See Repair Kit Listing on page 23 to determine the correct kit for your pump.


## Torque Sequence

Always follow torque sequence when instructed to torque fasteners.


1. Left/Right Fluid Cover  
Torque bolts to 14–17 N•m



3. Outlet Manifold  
Torque bolts to 14–17 N•m




2. Inlet Manifold  
Torque bolts to 14–17 N•m




# Dimensions

FRONT VIEW



SIDE VIEW




1 On aluminum pumps only.

02665B

02664

\* 1 in. npt on 810.0191, 810.0192, 810.0193, and 810.0194.

## PUMP MOUNTING HOLE PATTERN



02682

02681

## Technical Data

Maximum Fluid Working Pressure ..... 8.4 bar  
 Air Pressure Operating Range ..... 1.4–8.4 bar  
 Maximum Air Consumption ..... 1.68 N m<sup>3</sup>/min  
 Air Consumption at 4.9 bar/  
 76 l/min ..... 0.6 N m<sup>3</sup>/min (see chart)  
 Maximum Free Flow Delivery ..... 151 l/min  
 Maximum Pump Speed ..... 267 cpm  
 Liters per cycle ..... 0.57  
 Maximum Suction Lift ..... 5.48 m wet or dry  
 Maximum Size Pumpable Solids ..... 3.2 mm  
 \* Sound Pressure Level at 7 bar, full flow ..... 89 dBA  
 \* Sound Power Level at 7 bar, full flow ..... 100 dBA  
 \* Sound Pressure Level at 4.9 bar, 50 cycles/min ... 78 dBA  
 Maximum Operating Temperature ..... 65.5°C;  
 93.3°C for models with PTFE diaphragms  
 Air Inlet Size ..... 1/2 npt(f)  
 †Fluid Inlet Size ..... 1 in. bspt  
 †Fluid Outlet Size ..... 1 in. bspt

Wetted Parts ..... Vary by Model. Refer to pages 24–25.  
 Non-wetted External  
 Parts ..... Aluminum, 302, 316 Stainless Steel,  
 Polyester (labels)  
 Weight ..... *Aluminum Pumps*  
 with aluminum air motors: 8.2 kg  
 ..... *Stainless Steel Pumps*  
 with aluminum air motors: 15.0 kg  
 with stainless steel air motors: 22.0 kg


Loctite® is a registered trademark of the Loctite Corporation.

Santoprene® is a registered trademark of the Monsanto Co.

\* Sound pressure levels measured with the pump mounted on the floor, using Rubber Foot Kit 819.4333. Sound power measured per ISO Standard 9614–2.

† 1 in. npt for 810.0191, 810.0192, 810.0193, and 810.0194.

**Example of Finding Pump Air Consumption and Air Pressure at a Specific Fluid Delivery and Discharge Head:**  
 To supply 38 liters fluid flow (horizontal scale) at 1.4 bar discharge head pressure (vertical scale) requires approximately 0.28 N m<sup>3</sup>/min air consumption at 2.8 bar inlet air pressure.



### TEST CONDITIONS

The pump had a 2-piece PTFE diaphragm and was tested in water with the inlet submerged.



## Customer Services/Guarantee

### CUSTOMER SERVICES

If you require spare parts, please contact your local distributor, providing the following details:

- Pump Model
- Type
- Serial Number, and
- Date of First Order.

### GUARANTEE

All VERDER pumps are warranted to the original user against defects in workmanship or materials under normal use (rental use excluded) for two years after purchase date. This warranty does not cover failure of parts or components due to normal wear, damage or failure which in the judgement of VERDER arises from misuse.

Parts determined by VERDER to be defective in material or workmanship will be repaired or replaced.

### LIMITATION OF LIABILITY

To the extent allowable under applicable law, VERDER's liability for consequential damages is expressly disclaimed. VERDER's liability in all events is limited and shall not exceed the purchase price.

### WARRANTY DISCLAIMER

VERDER has made an effort to illustrate and describe the products in the enclosed brochure accurately; however, such illustrations and descriptions are for the sole purpose of identification and do not express or imply a warranty that the products are merchantable, or fit for a particular purpose, or that the products will necessarily conform to the illustration or descriptions.

### PRODUCT SUITABILITY

Many regions, states and localities have codes and regulations governing the sale, construction, installation and/or use of products for certain purposes, which may vary from those in neighbouring areas. While VERDER attempts to assure that its products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchasing and using a product, please review the product application as well as the national and local codes and regulations, and be sure that product, installation, and use complies with them.

Original instructions. This manual contains English.





# EU-DECLARATION OF CONFORMITY

EU-CONFORMITEITSVERKLARING, DÉCLARATION UE DE CONFORMITÉ, EU-KONFORMITÄTSEKTLÄRUNG DICHIARAZIONE DI CONFORMITÀ UE, EU-OVERENSSTEMMELSESEKTLÆRING, ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ ΕΕ, DECLARAÇÃO UE DE CONFORMIDADE, DECLARACIÓN UE DE CONFORMIDAD, EU-VAATIMUSTENMUKAISUUSVAKUUTUS, EU-FÖRSÄKRAN OM ÖVERENSSTÄMMELSE, EU PROHLÁŠENÍ O SHODĚ, ELI VASTAVUSDEKLARATSIOON, EU-MEGFELELŐSÉGI NYILATKOZAT, ES ATBILSTĪBAS DEKLARĀCIJA, ES ATITIKTIES DEKLARACIJA ZGODNOSCI UE, DIKJARAZZJONI TA' KONFORMITÀ TAL-UE, EU IZJAVA O SUKLADNOSTI, EU VYHLÁSENIE O ZHODE, ЕС ДЕКЛАРАЦИЯ ЗА СЪОТВЕТСТВИЕ, DECLARAȚIA UE DE CONFORMITATE

## Model

Modèle, Modell, Modello, Μοντέλο, Modelo, Malli, Mudel, Modelis, Mudell, Модел, Samhail

# VERDERAIR VA 25

## Part

Bestelnr., Type, Teil, Codice, Del, Μέρος, Peça, Referencia, Osa, Součást, Részegység, Dajka, Dalis, Część, Taqsima, Čast, Част, Páirt, Parte

810.0077–810.0079, 810.0081, 810.0085–810.0088, 810.0184, 810.0186, 810.0220–810.0267, 810.0269–810.0354, 810.0382, 810.0429, 810.0430, 810.0500–810.0547, 810.0549–810.0779, 810.0782, 810.2679–810.2924, 810.5460–810.5539, 810.5594–810.5628, 810.6346, 810.6347, 810.6975, 810.6977–810.6982, 810.7002, 810.7009, 810.7007, 810.7010, 810.7014–810.7018

## Complies With The EC Directives:

Voldoet aan de EG-richtlijnen, Conforme aux directives CE, Entspricht den EG-Richtlinien, Conforme alle direttive CE, Overholder EF-direktiverne, Σύμφωνα με ης Οδηγίες της ΕΚ, Em conformidade com as Directivas CE, Cumple las directivas de la CE, Täyttää EY-direktiivien vaatimukset, Uppfyller EG-direktiven, Shoda se směrnicemi ES, Vastab EÜ direktiividele, Kielégíti az EK irányelvek követelményeit, Atbilst EK direktivām, Atitinka šias ES direktyvas, Zgodnoš z Dyrektywami UE, Konformi mad-Direttivi tal-KE, V skladu z direktivami ES, Je v súlade so smernicami ES, Съвместимост с Директиви на ЕО, Tá ag teacht le Treoracha an CE, Respectă directivele CE

2006/42/EC Machinery Directive

2014/34/EU ATEX Directive (Ex II 2 GD c IIC T4) - Tech file stored with NB 0359

## Standards Used:

Gebruikte maatstaven, Normes respectées, Verwendete Normen, Norme applicate, Anvendte standarder, Πρόρρητα προς τρηζιμοποιήθηκαν, Normas utilizadas, Normas aplicadas, Sovellettavat standardit, Tillämpade standarder, Použité normy, Rakendatud standardid, Alkalmazott szabványok, Izmantotie standarti, Taikyti standartai, Užyte normy, Standards Užati, Uprabljeni standardi, Použité normy, Използвани стандарти, Caighdeáin arna n-úsáid, Standarde utilizate

EN 1127-1 EN 13463-1

ISO 12100 ISO 9614-1

## Notified Body for Directive

Aangemelde instantie voor richtlijn, Organisme notifié pour la directive, Benannte Stelle für diese Richtlinie, Ente certificatore della direttiva, Bemyndiget organ for direktiv, Διακοινωμένο όργανο Οδηγίας, Organismo notificado relativamente à directiva, Organismo notificado de la directiva, Direktiivin mukaisesti ilmoitettu tarkastuslaitos, Anmält organ för direktivet, Úředně oznámený orgán pro směrnici, Teavitatud asutus (direktiivi järgi), Az irányelvvél kapcsolatban értesített testület, Pilnvarotā iestāde saskaņā ar direktīvu, Apie direktīvu Informuota institūcija, Ciało powiadomione dla Dyrektywy, Korp avzat bid-Direttiva, Priglašeni organ za direktivo, Notifikovaný orgán pre smernicu, Нотифициран орган за Директива, Comhlacht ar tugadh fógra dó, Organism notificat în conformitate cu directiva

--	--	--	--

## Approved By:

Goedgekeurd door, Approuvé par, Genehmigt von, Approvato da, Godkendt af, Έγκριξη από, Aprovado por, Aprobado por, Hyväksynyt, Intygat av, Schwälit, Kinnitanud, Jóváhagyta, Apstiprināts, Patvirtino, Zatwierdzono przez, Approvat minn, Odobril, Schválené, Одобрено от, Fajoga ag, Aprobat de

Werner Bosman  
Managing Director

15 February 2017

VERDER BV  
Leningradweg 5  
9723 TP Groningen  
NETHERLANDS

819.5961

B

This declaration of conformity is issued under the sole responsibility of the manufacturer. Deze conformiteitsverklaring wordt verstrekt onder volledige verantwoordelijkheid van de fabrikant. La présente déclaration de conformité est établie sous la seule responsabilité du fabricant. Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller. La presente dichiarazione di conformità è rilasciata sotto la responsabilità esclusiva del fabbricante. Denne overensstemmelseerklæring udstedes på fabrikantens ansvar. Η παρούσα δήλωση ζυμμόρφωσης εκδίδεται με αποκλειστική ευθύνη του κατασκευαστή. A presente declaração de conformidade é emitida sob a exclusiva responsabilidade do fabricante. La presente declaración de conformidad se expide bajo la exclusiva responsabilidad del fabricante. Tämä vaatimustenmukaisuusvakuutus on annettu valmistajan yksinomisella vastuulla. Denna försäkrän om överensstämmelse utfärdas på tillverkarens eget ansvar. Toto prohlášení o shodě se vydává na výhradní odpovědnost výrobce. Käesolev vastavusdeklaratsioon on välja antud tootja ainuvastutusel. Ezt a megfelelőégi nyilatkozatot a gyártó kizárólagos felelőssége mellett adják ki. Šti atbilstības deklarācija ir izdota vienīgi uz ražotāja atbildību. Ši atitikties deklaracija išduota tik gamintojo atsakomybe. Nijiejsza deklaracja zgodności wydana zostaje na wyłączną odpowiedzialność producenta. Din idikjarazzjoni tal-konformità qiegħda tinħareġ taħt ir-responsabbiltà unika tal-manifattur. Ta izjava o skladnosti je izdana na lastno odgovornost proizvajalca. Toto vyhlázenie o zhode sa vydáva na výhradnú zodpovednosť výrobcu. Настоящата декларация за съответствие е издадена на отговорността на производителя. Prezenta declarație de conformitate este emisă pe răspunderea exclusivă a producătorului.

**Austria**

Verder Austria  
Eitnergasse 21/Top 8  
A-1230 Wien  
AUSTRIA  
Tel: +43 1 86 51 074 0  
Fax: +43 1 86 51 076  
e-mail: office@verder.at

**Belgium**

Verder nv  
Kontichsesteenweg 17  
B-2630 Aartselaar  
BELGIUM  
Tel: +32 3 877 11 12  
Fax: +32 3 877 05 75  
e-mail: info@verder.be

**China**

Verder Shanghai Instruments and Equipment Co., Ltd  
Building 8 Fuhai Business Park No. 299  
Bisheng Road, Zhangjiang Hiteck Park  
Shanghai 201204  
CHINA  
Tel: +86 21 33932950  
Fax: +86 21 33932955  
e-mail: info@verder.cn

**Bulgaria**

Verder Bulgaria Ltd  
Vitosh department,  
Manastriski Livadi Zapad  
district,  
110 Bulgaria Blvd., 2-nd  
Floor, apt. 15-16,  
1618 - Sofia  
BULGARIA  
Tel: 0878407370  
Fax: 02 9584085  
email: office@verder.bg

**Czech Republic**

Verder s.r.o.  
Vodnanská 651/6 (vchod  
Chlumecka 15)  
198 00 Praha 9-Kyje  
CZECH REPUBLIC  
Tel: +420 261 225 386-7  
Web: <http://www.verder.cz>  
e-mail: info@verder.cz

**Denmark**

Verder A/S  
Sales Denmark  
Leningradweg 5  
NL 9723 TP Groningen  
THE NETHERLANDS  
Tel: +45 3636 4600  
e-mail: info@verder.dk

**France**

Verder France  
Parc des Bellevues,  
Rue du Gros Chêne  
F-95610 Eragny sur Oise  
FRANCE  
Tel: +33 134 64 31 11  
Fax: +33 134 64 44 50  
e-mail: verder-  
info@verder.fr

**Germany**

Verder Deutschland GmbH  
Retsch-Allee 1-5  
42781 Haan  
GERMANY  
Tel: 02104/2333-200  
Fax: 02104/2333-299  
e-mail: info@verder.de

**Hungary**

Verder Hungary Kft  
Budafoke ut 187 - 189  
HU-1117 Budapest  
HUNGARY  
Tel: 0036 1 3651140  
Fax: 0036 1 3725232  
e-mail: info@verder.hu

**India**

Verder India Pumps Pvt  
Ltd.  
Plot No-3B, D-1 Block,  
MIDC Chinchwad,  
Pune - 411019  
INDIA  
e-mail:  
Sales@verder.co.in  
[www.verder.co.in](http://www.verder.co.in)

**Italy**

Verder Italia  
Via Maestri Del lavoro, 5  
02100 Vazia, Rieti  
ITALY  
Tel: +39 07 46 229064  
e-mail: info@verder.it

**The Netherlands**

Verder BV  
Leningradweg 5  
NL 9723 TP Groningen  
THE NETHERLANDS  
Tel: +31 50 549 59 00  
Fax: +31 50 549 59 01  
e-mail: info@verder.nl

**Poland**

Verder Polska  
ul.Ligonia 8/1  
PL-40 036 Katowice  
POLAND  
Tel: +48 32 78 15 032  
Fax: +48 32 78 15 034  
e-mail: verder@verder.pl

**Romania**

Verder România  
Drumul Balta Doamnei  
no 57-61  
Sector 3  
CP 72-117  
032624 Bucuresti  
ROMANIA  
Tel: +40 21 335 45 92  
Fax: +40 21 337 33 92  
e-mail: office@verder.ro

**Slovak Republik**

Verder Slovakia s.r.o.  
Silacska 1  
SK-831 02 Bratislava  
SLOVAK REPUBLIK  
Tel: +421 2 4463 07 88  
Fax: +421 2 4445 65 78  
e-mail: info@verder.sk

**South Africa**

Verder SA  
197 Flaming Rock Avenue  
Northlands Business Park  
Newmarket Street  
ZA Northriding  
SOUTH AFRICA  
Tel: +27 11 704 7500  
Fax: +27 11 704 7515  
e-mail: info@verder.co.za

**Switzerland**

Verder Deutschland GmbH  
Sales Switzerland  
Retsch-Allee 1-5  
D-42781 Haan  
GERMANY  
Tel: +41 (0)61 331 33 13  
Fax: +41 (0)61 331 63 22  
e-mail: info@verder.ch

**United Kingdom**

Verder UK Ltd.  
Unit 3 California Drive  
Castleford, WF10 5QH  
UNITED KINGDOM  
Tel: +44 (0) 1924 221 001  
Fax: +44 (0) 1132 465 649  
e-mail: info@verder.co.uk

**United States of America**

Verder Inc.  
312 Corporate Parkway  
Suite 101  
Macon, GA 31210  
USA  
Tel: +1 877 783 7337  
Fax: +1 478 476 9867  
e-mail: sales@verder-  
us.com