Repair/Parts

Verder VA-EH25 Electric-Operated

Diaphragm Pump

859.0531 Rev.D EN

For fluid transfer in sanitary applications. For professional use only.



Important Safety Instructions Read all warnings and instructions in this manual and in your Operation manual. **Save these instructions.**

For maximum operating pressures, see the Performance Charts on pages 19 and 20 of the Operation manual. See pages 3 and 4 for model information, including approvals.



Contents

Related Manuals	2
Configuration Number Matrix	3
Warnings	5
Overview	8
Troubleshooting1	0
Repair1	2
Pressure Relief Procedure 1	2
Check Valve Repair 1	3

23
28
20

Related Manuals

Manual Number	Title
859.0530	Verder VA-EH25 Electric-Operated Diaphragm Pump, Operation

Configuration Number Matrix

Check the identification plate (ID) for the Configuration Number of your pump. Use the following matrix to define the components of your pump.



Sample Configuration Number: VA-EH25SA SE NW SP T4 AC

VA-EH25	S	Α	SE	NW	SP	T4	AC
Pump Model	Wetted	Center	Seats	Balls	Diaphragm	Connections	Drive
	Section	Section					
	Material	Material					

Pump	We Ma	etted Section terial	Ce Ma	nter Section terial	Sea	t Material	Ball N	laterial
VA-EH25	S	Sanitary Stainless Steel	A	Aluminum	SE	Sanitary Stainless Steel with EPDM O-rings	NW	Polychloroprene Weighted
			S	Sanitary Stainless Steel	ST	Sanitary Stainless Steel with PTFE O-rings	SP	Santoprene
							TF	PTFE

Diaphra	agm Material	Connectio	ns	Drive	
ΤΟ	PTFE/EPDM Overmolded	D4	40 mm DIN 11851	AC	230/460 VAC
TF	2-piece PTFE/EPDM	T4	1.5 in. Tri-Clamp	NG [‡]	NEMA Gearbox
SP	Santoprene			IG _‡	IEC Gearbox

Approvals

Approvals				
All Models are certified to:	CE			
Models which do not contain Santoprene*:	ア 「			
‡ Pumps with code NG or IG are certified to:	II 2 G ck IIB T3 Gb			

* EC 1935/2004 compliant pumps may be subject to individual national provisions in addition to those specified in the EC regulation. It is the users responsibility to know and follow local laws.

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.







Overview

The product line offers electric-powered diaphragm pumps in a wide range of models. This section shows the structure of available models.

Center Section	Motor Type	Controller	Compressor	Approval Options	Cart
Aluminum or Stainless Steel	AC	VFD — not included.	No †	CE	No*
	Nana	Nene	NEMA		NI-*
	None	None None -		ATEX & CE	INO."

†Compressor Kits 859.0465 (120V) and 859.0466 (240V) are available

* Cart Kit 859.0467 is available.

Key Points:

- Pumps are available with an AC gearmotor or with just a gearbox (for applications where a motor is already available).
- Verder recommends the use of a motor soft starter or a VFD in the electrical circuit for all installations.

See the motor manufacturer's recommendations for proper installation when using either of these components. In all cases, make sure all products are installed in accordance with local codes and regulations.

Relationship Table

Use this table to locate your pump configuration number. Obtain the configuration number from the designation tag attached to the pump housing. Compare this configuration number against the information provided in the Configuration Number Matrix, page 3 to obtain the types of material being used. Then locate the applicable fluid section repair kit number for the pump.

Fluid Section Repair Kit	Seat Type	Ball Type	Diaphragm Type	Pump Configuration Number
859.0474	SE	NW	SP	VA-EH25SA SE NW SP T4 AC VA-EH25SA SE NW SP D4 AC VA-EH25SA SE NW SP T4 NG VA-EH25SA SE NW SP D4 NG VA-EH25SA SE NW SP T4 IG VA-EH25SA SE NW SP D4 IG
859.0475	ST	TF	то	VA-EH25SS ST TF TO T4 AC VA-EH25SS ST TF TO D4 AC VA-EH25SS ST TF TO T4 NG VA-EH25SS ST TF TO D4 NG VA-EH25SS ST TF TO T4 IG VA-EH25SS ST TF TO D4 IG

Fluid Section Repair Kit	Seat Type	Ball Type	Diaphragm Type	Pump Configuration Number
859.0476	ST	TF	TF	VA-EH25SA ST TF TF T4 AC VA-EH25SA ST TF TF D4 AC VA-EH25SS ST TF TF D4 AC VA-EH25SS ST TF TF D4 AC VA-EH25SA ST TF TF D4 AC VA-EH25SA ST TF TF D4 NG VA-EH25SS ST TF TF D4 NG VA-EH25SS ST TF TF D4 NG VA-EH25SA ST TF TF D4 IG VA-EH25SS ST TF TF D4 IG VA-EH25SS ST TF TF T4 IG VA-EH25SS ST TF TF D4 IG
859.0478	SE	SP	SP	VA-EH25SA SE SP SP T4 AC VA-EH25SA SE SP SP D4 AC VA-EH25SS SE SP SP T4 AC VA-EH25SS SE SP SP D4 AC VA-EH25SA SE SP SP D4 AC VA-EH25SA SE SP SP D4 NG VA-EH25SS SE SP SP D4 NG VA-EH25SS SE SP SP D4 NG VA-EH25SA SE SP SP D4 IG VA-EH25SS SE SP SP D4 IG VA-EH25SS SE SP SP T4 IG VA-EH25SS SE SP SP D4 IG

* Seat and o-ring kit 819.0537 available separately

Troubleshooting



- Follow the Pressure Relief Procedure, page 12, before checking or servicing the equipment.
- Check all possible problems and causes before disassembly.

Problem	Cause	Solution
Pump cycles but will not prime and/or pump.	Pump is running too fast, causing cavitation before prime.	Slow down the motor controller (VFD)
	Center section has no air pressure, or air pressure is too low.	Apply air pressure to center section per your application requirements.
	Check valve ball is severely worn or wedged in seat or manifold.	Replace the ball and seat.
	Insufficient suction pressure	Increase suction pressure. See manual 859.0530.
	Seat is severely worn.	Replace the ball and seat.
	Outlet or inlet is restricted.	Remove the restriction.
	Inlet fittings or manifolds are loose.	Tighten.
	Manifold o-rings are damaged.	Replace o-rings.
The center section is excessively hot.	The drive shaft is broken.	Replace.
Pump fails to hold fluid pressure at stall.	Check valve balls, seats, or o-rings are worn.	Replace.
	Manifold clamps or fluid cover clamps are loose.	Tighten.
	Diaphragm shaft bolt is loose	Tighten.
Pump will not cycle.	Motor or controller is wired improperly.	Wire per manual.
	The leak detector (if installed) has tripped.	Check diaphragm for rupture or incorrect installation. Repair or replace.
Pump flow rate is erratic.	Suction line is clogged.	Inspect; clear.
	Check balls are sticky or leaking .	Clean or replace.
	Diaphragm (or backup) ruptured.	Replace.
Pump makes unusual noises.	Pump is operating near or at stall pressure.	Adjust air pressure or slow the pump speed.
Air consumption is higher	A fitting is loose.	Tighten. Inspect thread sealant.
than expected.	Loose or damaged o-rings or shaft seal.	Replace.
	Diaphragm (or backup) ruptured.	Replace.

Problem	Cause	Solution				
Air bubbles in fluid.	Suction line is loose.	Tighten.				
	Diaphragm (or backup) ruptured.	Replace.				
	Loose manifolds, damaged seats or o-rings.	Tighten manifold bolts or replace seats or o-rings.				
	Loose diaphragm shaft bolt.	Tighten.				
Pump leaks fluid externally from joints.	Loose manifold clamps or fluid cover clamps.	Tighten.				
	Manifold o-rings worn out.	Replace o-rings.				
The controller faults or shuts down.	A GFCI has tripped.	Remove the controller from the GFCI circuit.				
	Supply power is poor.	Determine and fix the source of the power problem.				
	Operational parameters are exceeded.	See manual 859.0530 for event codes.				
NOTE: For problems with a Va	NOTE: For problems with a Variable Frequency Drive (VFD), see your VFD manual.					

Repair

Pressure Relief Procedure



Follow the Pressure Relief Procedure whenever you see this symbol.



This equipment stays pressurized until pressure is relieved manually. To help prevent serious injury from pressurized fluid, such as splashing in the eyes or on skin, follow the Pressure Relief Procedure when you stop pumping and before you clean, check, or service the equipment.

- 1. Remove power from the system.
- 2. Open the dispensing valve, if used.
- 3. Open the fluid drain valve to relieve fluid pressure. Have a container ready to catch the drainage.
- 4. Close the pump air inlet valve on the pneumatic enclosure.
- 5. **Units with a compressor:** Cycle the valve to bleed any remaining air.

Check Valve Repair



NOTE: Kits are available for new check valve balls, diaphragms, and manifold o-rings in a range of materials. A seat and manifold o-ring kit is also available.

NOTE: To ensure proper seating of the check balls, always inspect the seats when replacing the balls. Replace seats as necessary if seating surface shows evidence of wear.

Disassemble the Check Valves

- 1. Follow the Pressure Relief Procedure, page 12. Remove power from the motor. Disconnect all hoses.
- 2. Remove the manifold clamps (6), then remove the outlet manifold (3).
- 3. Remove the o-rings (9), seats (7), and balls (8).
- 4. Repeat for the inlet manifold (4), o-rings (9), seats (7), and balls (8).

To continue disassembly, see Disassemble the Diaphragms, page 14.

Reassemble the Check Valves

- 1. Clean all parts and inspect for wear or damage. Replace parts as needed.
- Reassemble in the reverse order, following all notes in the illustration. Put the inlet manifold on first. Be sure the ball checks (7–9) and manifolds (3, 4) are assembled **exactly** as shown. The arrows on the fluid covers (2) **must** point toward the outlet manifold (3).



Arrow on both covers must point toward outlet manifold

Diaphragm Repair



Disassemble the Diaphragms

NOTE: Diaphragm kits are available in a range of materials and styles. See Parts section.

- 1. Follow the Pressure Relief Procedure, page 12. Remove power from the motor. Disconnect all hoses.
- 2. Remove the manifolds and disassemble the ball check valves as explained in Check Valve Repair, page 13.
- 3. Remove the clamps (5) from the fluid covers, then pull the fluid covers off of the pump.



4. Loosen the screws and remove the motor fan cover. Turn the motor fan by hand to move the piston fully to one side.

NOTE: If the pump is still attached to the motor, remove the plug (124) and o-ring (134). Use a 10 mm socket to rotate the shaft clockwise to shift the piston to one side. Socket should move easily [no more than 1.7 N•m (15 in-lb) of torque]. If more torque is required, stop. Remove the motor. See Center Section Repair, page 17

5. Overmolded Diaphragms (TO models)

- a. Hold a 5/8 in. wrench on the wrench flats of the exposed piston shaft. The diaphragm (12) will screw off by hand. Remove the air side diaphragm plate (11).
- b. Turn the motor fan to move the piston fully to the other side by rotating the drive shaft. Repeat step 5a.

6. All Other Diaphragms

- a. Hold a 5/8 in. wrench on the wrench flats of the exposed piston shaft. Use a 15 mm wrench on the shaft bolt (15) to remove it. Then remove all parts of the diaphragm assembly.
- b. Turn the motor fan to move the piston fully to the other side by rotating the drive shaft. Repeat step 6a.
- 7. To continue with disassembly, see Disassemble the Center Section, page 17.

Reassemble the Diaphragms

Follow all notes in the illustrations on page 15. These notes contain **important** information.

NOTICE

After reassembly, allow the thread locker to cure for 12 hours, or per manufacturer's instructions, prior to operating the pump. Damage to the pump will occur if the diaphragm shaft bolt loosens.

TIP: If you are also repairing or servicing the center section (drive shaft, piston, etc.), see Center Section Repair, page 17, before you put the diaphragms back on.

 Clean all parts and inspect for wear or damage. Replace parts as needed. Be sure the center section is clean and dry.

2. Overmolded Diaphragms (TO)

- a. If a diaphragm setscrew comes loose or is replaced, apply permanent (red) thread locker to diaphragm side threads. Screw into diaphragm until tight.
- b. Assemble the air side plate (11) onto the diaphragm. The rounded side of the plate must face the diaphragm.
- c. Clean the female threads of the piston shaft with a wire brush dipped in solvent to remove any residual thread locker. Apply thread-locking primer and allow it to dry.
- d. Thoroughly clean, then apply medium-strength (blue) thread locker to the threads of the diaphragm assembly.
- e. Hold a 5/8 in. wrench on the wrench flats of the piston shaft. Screw the assembly into the shaft as tight as possible by hand.
- f. Turn the motor fan to move the piston fully to the one side by rotating the drive shaft. See instructions in step 4 of Disassemble the Diaphragms, page 14.
- g. Repeat to install the other diaphragm assembly.

3. All Other Diaphragms-Metal Pumps

- a. Thoroughly clean or replace the diaphragm bolt (14). Install the o-ring (15).
- b. Assemble the fluid side plate (10), the diaphragm (12), the backup diaphragm (13, if present), and the air side diaphragm plate (11) on the bolt exactly as shown.
- c. Clean the female threads of the piston shaft with a wire brush dipped in solvent to remove any residual thread locker. Apply thread-locking primer and allow it to dry.
- d. Apply medium-strength (blue) thread locker to the threads of the bolt.
- e. Hold a 5/8 in. wrench on the wrench flats of the piston shaft. Screw the bolt onto the shaft and torque to 81–95 N•m (60–70 ft-lb).
- f. Turn the motor fan to move the piston fully to the other side by rotating the drive shaft. See instructions in step 4 of Disassemble the Diaphragms, page 14.
- g. Repeat to install the other diaphragm assembly.
- 4. Attach the fluid covers. The arrow on each fluid cover must point toward the outlet manifold. Tighten the mounting clamp (5).
- 5. Reassemble the check valves and manifolds. See Reassemble the Check Valves, page 13.

Repair



Overmolded (TO) Models



Standard (SP) Models

ti27373a

NOTICE

After reassembly, allow the thread locker to cure for 12 hours, or per manufacturer's instructions, prior to operating the pump. Damage to the pump will occur if the diaphragm shaft bolt loosens.

Center Section Repair



Disassemble the Center Section

See the illustrations on page 17.

- 1. Follow the Pressure Relief Procedure, page 12. Remove power from the motor. Disconnect all hoses.
- Remove the manifolds and check valve parts as directed in Disassemble the Check Valves, page 13.
- Remove the fluid covers and diaphragms as directed in Disassemble the Diaphragms, page 14.

TIP: Clamp the gear box bracket (27) to the bench. Leave the pump connected to the motor.

4. Use a 5 mm hex wrench to remove 4 bolts (117). Pull the pump off of the alignment housing (116).

TIP: It may be necessary to tap the pump with a rubber mallet to disengage the coupler.

5. Use a 5/16 hex wrench to remove the plug (124). Use a 30 mm socket wrench to remove the bearing bolt (106) and the o-ring (108) from the top.

- 6. Turn the shaft so the groove (G) on the drive shaft (112) is at the top, in line with the alignment mark (A) on the center housing.
- 7. Use a 3/4–16 bolt, screwed into the hole for plug (124), to push out the drive shaft (112). You can also use the bearing bolt (106), but remove the bearing (107) first. Be sure that the groove on the drive shaft remains aligned with the markings in the center section.

NOTICE

Proper alignment is essential. Do not apply more than about 1.1 N•m (10 in-lb) of torque. Excessive torque could strip the housing thread. If you encounter resistance, check drive shaft alignment or contact your distributor.

- 8. Remove the seal cartridge (110), the o-ring (109) and the radial seal (111) with o-ring (111a).
- 9. Slide the piston assembly (102) out of the center.
- 10. Leave the gearbox coupler (114) attached to the gearbox (118) shaft unless it is damaged. If you need to remove it, first remove the alignment housing (116). Use an 8 mm hex wrench to loosen the screw (115), then remove the gearbox coupler (114).

NOTE: If the coupler does not come off freely, use a bearing puller to remove it. Do not use any prying tools, as damage to the mounting flange on the gearbox could occur.

Repair



Reassemble the Center Section

See the illustrations on page 17.

- 1. Clean and dry the center housing (101), the center of the piston (102) and the drive shaft (112).
- Inspect the piston for excessive wear and replace if needed. Grease the piston as shown on page 18 and install it in the center section with the groove on the top, in line with the bearing bolt (106) hole in the center section.
- Install the bearing (107 [if removed from the bearing bolt]), o-ring (108), and the bearing bolt (106). Apply medium-strength (blue) thread locker to the bearing bolt. Be sure that the bearing (107) is in the groove on the piston, as shown. Be sure that the piston moves freely. Torque the bolt to 20–34 N•m (15–25 ft-lb).



4. Be sure the sealing surface of the drive shaft (112) is clean. Install the seal cartridge (110†) and the radial seal (111†) on the drive shaft. Be sure the o-ring (111a†) is on the radial seal. The lips on the radial seal (111†) must face **IN** toward the center.



- 5. Install o-ring (109†).
- 6. Apply anti-seize lubricant on the mating surfaces of the drive shaft, as shown in the illustration, page 18.
- 7. Center the piston in the housing and install the drive shaft assembly (112), with the groove (G) facing up, into the center housing (101).
- 8. Inspect the shaft coupler (114) for wear and replace if needed. Install on the drive shaft.
- If removed, install the gearbox coupler (114) on the shaft. Apply medium strength thread locker and install the screw (115). Torque to 47–61 N•m (35–45 ft-lb). Then install the alignment housing (116) and lifting bracket (139) on the gearbox using the screws (120, 122), washers (119). Torque to 15–18 N•m (130–160 in-lb).
- 10. Install the alignment housing o-ring (130) on the housing (101).
- 11. Be sure the gearbox coupler (114) is aligned properly. Turn by hand if needed. Connect the pump to the gearbox assembly, engaging the couplers.
- Apply medium-strength (blue) thread locker and install the housing screws (117). Tighten about 5 turns at a time, in a crisscross pattern, to fully engage the coupler. Torque to 15–18 N•m (130–160 in-lb).
- 13. Be sure o-ring (134) is on the plug (124). Install the plug and torque to 20–34 N•m (15–25 ft-lb).
- 14. See Reassemble the Diaphragms, page 15, and Reassemble the Check Valves, page 13.

Replace Center Bearing

NOTE: Follow this procedure only if you suspect that the center bearing is damaged. It is not necessary to replace the bearing for normal pump service. You will need Center Section Repair Tool Kit 859.0507. You also will need Bearing Puller Kit 859.0529. The tool (A) was designed to work with this bearing puller.

- 1. Follow all steps in Disassemble the Center Section, page 17.
- 2. Clamp the center housing (101) in a vise, with one of the bushings facing up.
- 3. Place the repair tool (A) on the housing with the grooved side down.
- 4. Remove the bushing (C). Use the upper holes on the medium-sized jaw, and the inner holes on the puller. Be sure that the jaws engage the bottom rim of the bushing. When one bushing is out, turn the housing over and repeat for the other bushing.



5. Place the center housing (101) in the vise with the bearing (D) side on the bottom.

- 6. Place the repair tool (A) on the housing with the stepped side down.
- 7. Remove the bearing (D). Use the lower holes on the medium-sized jaw, and the outer holes on the puller.



Use an arbor press to install the new bearing (D) into the center housing (101). Press the bearing to the shoulder in the center housing.



9. Use an arbor press and the press-fit tool (E) to install the two bushings (C). Install the bushings flush with the center housing (101).



10. Follow all steps in Reassemble the Center Section, page 19.

Replace the Compressor



To avoid injury from fire, explosion, or electric shock, all electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.

- Remove the air line (A1) from the compressor. Disconnect the compressor wires at the terminal block (L1, L2, and ground). Remove the four bolts, and carefully pull the compressor out of the box.
- 2. Use the 4 bolts and 4 lock washers to install the new compressor. Apply medium-strength (blue) thread locker to the threads. Connect the air line from A1 to A1, as shown.
- 3. Connect the wires from the new compressor to the terminal block, as shown.
- 4. Return the pump to its mounting location. Secure it with the 8 bolts.
- 5. Return power to the pump.





KEY



Parts



Parts

Parts/Kits Quick Reference

Use this table as a quick reference for parts/kits. Go to the pages indicated in the table for a full description of kit contents.

Ref.	Part/Kit	Description	Qty.
1		MODULE, drive	1
2	819.0490	COVER, fluid	2
3		MANIFOLD, outlet, SST	1
	819.0494	Tri-Clamp	
	819.0618	DIN	
4		MANIFOLD, inlet, SST	1
	819.0493	Tri-Clamp	
	819.0617	DIN	
5	819.0522	CLAMP, cover	2
6	819.0505	CLAMP, Tri-Clamp	4
7	819.0537	SEAT, includes o-rings	4
0		(Ref. 9); see page 24	4
8		BALLS, CNECK	4
	819.0545	Polychloroprene weighted	
	819.0426	PTFE	
	819.0427	Santoprene	
9		O-RING, manifold	4
	819.0550*	PTFE	
	819.0540*	EPDM	
10	819.0508	PLATE, fluid side, SST, for	2
		PT & SP diaprhragms	
11		PLATE, air side, aluminum	2
	819.0446	for TF & SP diaphragms	
	819.0534	for TO diaphragms	
12		DIAPHRAGM, kit; see	1 kit
	050 0400	page 25	
	009.0400	Santoprene Standard (SP)	
	859.0479	PIFE Overmolded (10)	
	859.0481	PTFE/EPDM 2-Piece (TF)	

Ref.	Part/Kit	Description	Qty.
13		DIAPHRAGM, backup,	2
		included with TF	
		diaphragm (Ref. 12).	
14	859.0085	BOLT, diaphragm; kit;	2
		includes o-ring (ref. 15)	
15	819.0420	PACKING, o-ring, for	2
	or none	models with Santoprene	
		or PTFE/EPDM 2-Piece	
		diaphragm (Ref. 12)	
19▲	859.0527	LABEL, safety	1
27	859.0464	BRACKET, gearbox	1
		mounting, includes 27a,	
		27b, 27c	
27a		SCREW, cap, hex head,	4
		5/16–18 x 1.5 in.	
27b		WASHER, lock	4
27c		WASHER, flat,	4
28	859.0468	ENCLOSURE, pneumatic,	1
		includes 28a, 28b, 28c	
28a		SCREW, cap, socket head,	4
		10–24 x 3/4 in.	
28b		WASHER	8
28c		NUT	4

▲ Replacement Warning labels, signs, tags, and cards are available at no cost.

* These parts are included in the fluid section repair kit which may be purchased separately. Refer to the **Relationship Table**, page 8 to determine the kit for your pump.

Drive Module

Sample Configuration Number

Pump	Wetted	Center	Seats	Balls	Diaphragms	Connections	Drive
Model	Section	Section			_		
	Material	Material					
VA-EH25	S	Α	SE	NW	SP	T4	AC



Ref	Part	Description	Qty
101		HOUSING, center,	1
		assembly; includes	
		items (Ref. 123, 124,	
		134)	
	859.0461	Aluminum (A)	
	859.0462	Stainless Steel (<mark>S</mark>)	
102	859.0509	PISTON, kit	1
106		BOLT, bearing; includes	1
		Ref. 107 and Ref. 108	
	859.0493	for aluminum center	
		housing (A)	
	859.0494	for stainless steel center	
		housing (<mark>S</mark>)	
107		BEARING, cam follower.	1
		included with Ref. 106	
108		O-RING, Size 019,	1
		Fluoroelastomer;	
		included with Ref. 106	
109†		O-RING, Size 153,	1
		Buna-N	
110†		CARTRIDGE, seal	1
111†		SEAL, radial, includes	1
		o-ring (Ref. 111a)	
111a†		O-RING, seal	1
112	859.0485	SHAFT, drive, assembly;	1
		includes o-ring (Ref.	
		109), cartridge (Ref.	
		110) and seal (Ref. 111	
		and 111a)	
113	859.0484	COUPLER, shaft	1
114	859.0483	COUPLER, gearbox;	1
		Includes screw (ref. 115)	
115		SCREW, socket head,	1
		M10 x 30 mm	
116		HOUSING, alignment,	1
		assembly; includes	
		screws (Refs. 117 and	
		128) and access cover	
		(Ref. 126)	
	859.0470	Aluminum	
	859.0469	Stainless steel	

Ref	Part	Description	Qty
117		SCREW, socket head, M6 x 40 mm	4
118		GEARBOX,	1
	859.0521	NEMA (NG)	
	859.0520	IEC (IG)	
119		WASHER	4
120		SCREW, cap, hex head, M6 x 16 mm	2
122		SCREW, cap, hex head, M6 x 20 mm	2
123		PLUG, pipe, headless	1
124	859.0495	PLUG, front access includes o-ring (Ref. 134)	1
125	819.0679	SCREW, ground, M5 x 0.8	1
126	859.0471	COVER, access; includes items (Ref. 128, 129, 133)	1
128		SCREW, button head, M6 x 6 mm	2
129		WASHER	2
131	859.0472	PACKING, o-ring	1
132‡		SCREW, cap, hex head, 3/8–16 x 1 in. (BLDC only)	4
133		GASKET	1
134		O-RING	1
139	859.0534	RING, Lift	1
140▲		FITTING, 1/8 npt	1
141▲		FITTING, elbow	1
142▲		TUBE	1
143	859.0459	GEARMOTOR, AC; includes items (Ref. 119, 120, 122)	1

† Included in Shaft Seal Repair Kit 859.0496.

‡ Included in Motor Kit 859.0460.

▲Included in Fitting Kit 859.0533.

Seats

Sample Configuration Number

Pump Model	Wetted Section Material	Center Section Material	Seats	Balls	Diaphragms	Connections	Drive
VA-EH25	S	А	SE	NW	SP	T4	AC

Seat Kits			
SE	819.0537		
ST	819.0537		

Kits include:

- 4 SST seats (7)
- 4 PTFE o-rings (9)
- 4 EPDM o-rings (9)

Diaphragms

Sample Configuration Number

Pump Model	Wetted Section Material	Center Section Material	Seats	Balls	Diaphragms	Connections	Drive
VA-EH25	S	А	SE	NW	TF	T4	AC

12 12 12 12 12 12 12 12 12	SP	Santoprene Diaphragm Kit 859.0480 includes: • Kits include: 2 diaphragms (12)
S 12	то	 PTFE/EPDM Overmolded Diaphragm Kit 859.0479 includes: 2 overmolded diaphragms (12) with set screws (S) 1 packet anaerobic adhesive 1 packet sealant
13 12 12 12 12 12 12 12 12 12 12 12 12 12	TF	 PTFE/EPDM 2-Piece Diaphragm Kit 859.0481 includes: 2 diaphragms (12) 2 backup diaphragms (13)

Kits and Accessories

Leak Sensor Kit 859.0508

Upgrade kit, to add a leak sensor to an existing system. Includes leak sensor and bushing.

Leak Sensor Cables; Field Wireable (for VFDs)

M8, 4-pin

Part	Description
859.0517	9.8 ft; 3.0 m
859.0518	24.6 ft; 7.5 m
859.0519	52.5 ft; 16 m

Compressor Kits 859.0504 (120V) and 859.0505 (240V)

Kit contains only a compressor.

Compressor Upgrade Kits 859.0465 (120V) and 859.0466 (240V)

Upgrade kits include compressor, compressor box, brackets, and mounting hardware.

Center Section Repair Tool Kit 859.0507

Includes tools needed to remove the bearing from the center section.

Bearing Puller Kit 859.0529

Includes an interchangeable bearing puller set.

Sanitary Cart Kit 859.0467

Stainless steel cart with wheels.

ATEX Motor Kit 859.0523

(For European hazardous locations)

Kit contains motor and SST mounting harware. Motor is ATEX rated II2 G Ex d IIB T3 Gb; IP55. Mounting flange is IEC90 B5 and fits pumps with gearbox 859.0520 and pumps with gearbox and motor configuration code **IG**.

Explosion-Proof Motor Kit 859.0522

(For North American hazardous locations)

Kit contains motor and SST mounting harware. Motor is rated Class I Group C & D; Class II Group F & G; IP54. Mounting flange face dimensions are NEMA 56 C and fits gearbox 859.0521 and pumps with gearbox and motor configuration code NG.

Technical Data

	US	Metric		
Verder VA-EH25 Electric-Operated Double Diaphragm Pur	np			
Maximum fluid working pressure	70 psi	4.8 bar, 0.48 MPa		
Air pressure operating range	20 to 80 psi	1.4 to 5.5 bar, 0.14 to 0.55 MPa		
Air inlet size	3/8 in.	npt(f)		
Maximum suction lift (reduced if balls don't seat well due	Wet: 29 ft	Wet: 8.8 m		
to damaged balls or seats, lightweight balls, or extreme speed of cycling)	Dry: 16 ft	Dry: 4.9 m		
Maximum size pumpable solids	1/8 in.	3.2 mm		
Ambient air temperature range for operation and storage. NOTE: Exposure to extreme low temperatures may result in damage to plastic parts.	32° F–104° F	0° C–40° C		
Fluid displacement per cycle	0.10 gallons	0.38 liters		
Maximum free-flow delivery	35 gpm	132.5 lpm		
Maximum pump speed	280	cpm		
Fluid Inlet and Outlet Size	1.5 in. sanitary flange or 40 mm DIN 11851			
Electric Motor				
AC, Standard CE				
Power	1.5 kW			
Speed	1800 rpm (60 Hz) o	r 1500 rpm (50 Hz)		
Gear Ratio	8.16			
Voltage	3-phase 230V / 3-Phase 460V			
Motorless Gearbox				
NEMA (NG)				
Mounting Flange	NEMA 56 C			
Gear Ratio	18.08			
IEC (IG)				
Mounting Flange	IEC 90			
Gear Ratio	18.	08		
Noise Data				
Sound Power (measured per ISO-9614–2)				
at 4.8 bar fluid pressure and 50 cpm	71 (dBa		
at 2.76 bar fluid pressure and 280 cpm (full flow)	94 dBa			
Sound Pressure [tested 1 m (3.28 ft) from equipment]				
at 4.8 bar fluid pressure and 50 cpm	61 dBa			
at 2.76 bar fluid pressure and 280 cpm (full flow)	84 dBa			

Weights (typical only)

Pump Material	Motor/Gearbox						
		AC		NEMA NG		IEC IG	
Fluid Section	Center Section	lb	kg	lb	kg	lb	kg
Stainless Steel	Aluminum	136	62	99	45	104	47
Stainless Steel	Stainless Steel	166	75	129	58	134	61

Weight				
Compressor	28 lb	13 kg		
Cart	33 lb	15 kg		
Wetted Parts				
Wetted parts include stainless steel, plus material(s) chosen for seat, ball, and diaphragm options				
Non-wetted parts				
Aluminum, coated carbon steel, bronze				
Stainless Steel, aluminum, coated carbon steel, bronze				

Fluid Temperature Range

Temperature limits are based on mechanical stress only. Certain chemicals will further limit the fluid temperature range. Stay within the temperature range of the most-restricted wetted component. Operating at a fluid temperature that is too high or too low for the components of your pump may cause equipment damage.

NOTICE

	Fluid Temperature Range	
Diaphragm/Ball/Seat Material	Fahrenheit	Celsius
Polychloroprene check balls (NW)	40° to 200°F	4° to 90°C
PTFE overmolded diaphragm (TO)	40° to 220°F	4° to 104°C
PTFE check balls or two-piece PTFE/EPDM diaphragm (TF)	40° to 220°F	4° to 104°C
Santoprene® check balls or 2-piece PTFE/Santoprene diaphragm (SP)	-40° to 180°F	-40° to 82°C

Customer Services/Guarantee

CUSTOMER SERVICES

If you require spare parts, please contact your local distributor, providing the following details:

- Pump Model
- Type
- · Serial Number, and
- · Date of First Order.

GUARANTEE

All VERDER pumps are warranted to the original user against defects in workmanship or materials under normal use (rental use excluded) for two years after purchase date. This warranty does not cover failure of parts or components due to normal wear, damage or failure which in the judgement of VERDER arises from misuse.

Parts determined by VERDER to be defective in material or workmanship will be repaired or replaced.

LIMITATION OF LIABILITY

To the extent allowable under applicable law, VERDER's liability for consequential damages is expressly disclaimed. VERDER's liability in all events is limited and shall not exceed the purchase price.

WARRANTY DISCLAIMER

VERDER has made an effort to illustrate and describe the products in the enclosed brochure accurately; however, such illustrations and descriptions are for the sole purpose of identification and do not express or imply a warranty that the products are merchantable, or fit for a particular purpose, or that the products will necessarily conform to the illustration or descriptions.

PRODUCT SUITABILITY

Many regions, states and localities have codes and regulations governing the sale, construction, installation and/or use of products for certain purposes, which may vary from those in neighboring areas. While VERDER attempts to assure that its products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchasing and using a product, please review the product application as well as the national and local codes and regulations, and be sure that product, installation, and use complies with them.

Original instructions. This manual contains English.

Revision D, June 2016

Austria Verder Austria Eitnergasse 21/Top 8 A-1230 Wien AUSTRIA Tel: +43 1 86 51 074 0 Fax: +43 1 86 51 076 e-mail: office@verder.at	Belgium Verder nv Kontichsesteenweg 17 B–2630 Aartselaar BELGIUM Tel: +32 3 877 11 12 Fax: +32 3 877 05 75 e-mail: info@verder.be	China Verder Retsch Shanghai Trading, Building 8 Fuhai Business Park No. 299 Bisheng Road, Zhangjiang Hiteck Park Shanghai 20120 CHINA Tel: +86 (0)21 33 93 29 50 / 33 93 29 51 Fax: +86 (0)21 33 93 29 55 e-mail: info@verder.cn	
Bulgaria Verder Bulgaria Ltd Vitosh department, Manastriski Livadi Zapad district, 110 Bulgaria Blvd., 2-nd Floor, apt. 15-16, 1618 - Sofia BULGARIA Tel: 0878407370 Fax: 02 9584085 email: office@verder.bg	Czech Republic Verder s.r.o. Vodnanská 651/6 (vchod Chlumecka 15) 198 00 Praha 9-Kyje CZECH REPUBLIC Tel: +420 261 225 386-7 Web: http://www.verder.cz e-mail: info@verder.cz	Denmark Verder A/S H.J. Holstvej 26 DK 2610 Rodovre DENMARK Tel: +45 3636 4600 e-mail: info@verder.dk	France Verder France Parc des Bellevues, Rue du Gros Chêne F–95610 Eragny sur Oise FRANCE Tel: +33 134 64 31 11 Fax: +33 134 64 44 50 e-mail: verder- info@verder.fr
Germany Verder Deutschland GmbH Retsch-Allee 1-5 42781 Haan GERMANY Tel: 02104/2333-200 Fax: 02104/2333-299 e-mail: info@verder.de	Hungary Verder Hongary Kft Budafoke ut 187 - 189 HU-1117 Budapest HUNGARY Tel: 0036 1 3651140 Fax: 0036 1 3725232 e-mail: info@verder.hu	Italy Verder Italia Via Maestri Del Iavoro, 5 02100 Vazia, Rieti ITALY Tel: +39 07 46 229064 e-mail: info@verder.it	India Verder India Pumps PVT. LTD Plot No-3b+3part 11, D-1 Block, MIDC Block Chinchwad, Pune - 411019 INDIA e-mail: Sales@verder.co.in www.verder.co.in
The Netherlands Verder BV Leningradweg 5 NL 9723 TP Groningen THE NETHERLANDS Tel: +31 50 549 59 00 Fax: +31 50 549 59 01 e-mail: info@verder.nl	Poland Verder Polska ul.Ligonia 8/1 PL-40 036 Katowice POLAND Tel: +48 32 78 15 032 Fax: +48 32 78 15 034 e-mail: verder@verder.pl	Romania Verder România Drumul Balta Doamnei no 57-61 Sector 3 CP 72-117 032624 Bucuresti ROMANIA Tel: +40 21 335 45 92 Fax: +40 21 337 33 92 e-mail: office@verder.ro	Slovak Republik Verder Slovakia s.r.o. Silacska 1 SK-831 02 Bratislava SLOVAK REPUBLIK Tel: +421 2 4463 07 88 Fax: +421 2 4445 65 78 e-mail: info@verder.sk
South Africa Verder SA 197 Flaming Rock Avenue Northlands Business Park Newmarket Street ZA Northriding SOUTH AFRICA Tel: +27 11 704 7500 Fax: +27 11 704 7515 e-mail: info@verder.co.za	Switzerland Verder Deutschland GmbH Sales Switzerland Retsch-Allee 1–5 D-42781 Haan GERMANY Tel: +41 (0)61 331 33 13 Fax: +41 (0)61 331 63 22 e-mail: info@verder.ch	United Kingdom Verder UK Ltd. Unit 3 California Drive Castleford, WF10 5QH UNITED KINGDOM Tel: +44 (0) 1924 221 001 Fax: +44 (0) 1132 465 649 e-mail: info@verder.co.uk	United States of America Verder Inc. 110 Gateway Drive Macon, GA 31210 USA Toll Free: 18777 VERDER Tel: +1 478 471 7327 Fax: +1 478 476 9867 e-mail: info@verder.com