VERDERHUS THE CLOG FREE, EFFICIENT PUMP

VERDER**HUS**®



VERDERHUS PRODUCT OVERVIEW

Screw Centrifugal Pumps

Benefits

→ Reduced maintenance cost

→ Clog free pumping

→ High efficiency





A well-functioning pump helps you succeed. That applies certainly to the most important pump in life, the human heart, but the same goes for pumps in business. At Verder, all energy and attention is focused on improving the quality and performance all of our pumps and services. We do so with energy, dedication and most importantly, with our heart.

VERDER – PASSION FOR PUMPS



- 🔺 1 Company
- → 26 Countries
- 55 Years of expertise
- Global network
- Local distributors
- → In-house service & maintenance
- A solution for every application

THE VERDER GROUP

The Verder group is a family owned business formed over 55 years ago in the Netherlands; the group consists of a worldwide network of production and distribution companies. Group companies are involved in the development and distribution of industrial pumps, pumping systems, high-tech equipment for quality control, research and development into solid material (solids sample preparation and analytical technologies). The Verder Group employs over 1600 people and has an annual turnover is in excess of 380 million Euros.

Among the most successful of Verder's technologies is its innovative Verderhus screw centrifugal pump range.

Verderhus screw centrifugal pumps

Verderhus screw centrifugal pumps combine the best features of centrifugal and positive displacement pumps to define a new standard for low head, high flow pumping. Each Verderhus pump has a large clearance, screw impeller gently feeding product into the pump chamber and efficiently transferring it to the discharge line. The open impeller allows large solids to be easily pumped, whilst the screw design is ideal for high solid contents or viscous liquids and produces a high efficiency, low NPSHr pump, lowering both energy use and ownership costs.





Features

- → *High viscous pumping:* The combination of properties of a centrifugal and positive displacement technology enables pumping of high viscous fluids up to 3000cPs.
- Low shear pumping: The gentle action of the impeller shape avoids any emulsification and protects from floc damage in active sludges for example.
- Solid Handling: The free passage of the screw impeller design can enable large solids up to 80% of the discharge flange and that can mean particles up to 160 mm in diameter.
- → High efficiency: Due to the innovative design efficiencies can be up to 70% at BEP that reduces energy costs over more traditional technologies.
- Wear protection: Using the best choice of materials and coatings can protect the pump from abrasion, also assisted by the ability of adjusting the impeller casing gap which extends the life of the pump and maintains efficiency.



Materials

Housing	Cast Iron (GG25)	option 316/1.4408
Impeller	Ductile Iron (GGG50)	option 316/1.4408
Bearing housing	Cast Iron (GG25)	option 316/1.4408

Seal Specification	Product Side	Motor Side
Rotating Face	SIC	Carbon
Static Face	SIC	Ceramic
Elastomer	Viton	NBR

HOW DOES A SCREW CENTRIFUGAL PUMP WORK?

The Verderhus pump is unique in that it operates a hybrid principle of both a centrifugal and positive displacement action. The hybrid pumping principle is possible due to the screw centrifugal impeller and cone assembly; unique to this category of pump. The contour and shape of the impeller produces compression, similar to a positive displacement pump.

This principle is combined with an open screw to allow the easy passage of large solids. Towards the discharge end of the impeller the diameter increases and the channel contour steepens. In this way the velocity of the fluid is increased, generating centrifugal force, typical of a radial action centrifugal pump. The cone shape of the pump casing matches the impeller's increasing screw diameter. The screw provides a close tolerance to achieve efficiencies as high as 70%. The impeller provides easy passage for larger solids, slurry and sludge.



What are your benefits using a Verderhus Screw Centrifugal pump?

Reduced maintenance cost

In a screw centrifugal pump the screw is the part most prone to wear. Verderhus impellers are designed oversize and available in hardened materials to decrease this effect meaning less maintenance and downtime to your process.

Clog free pumping

Solid sizes up to 80% of the discharge size which in some case can mean solids up to 160 mm in diameter.

Efficient pumping of high viscous fluids

The hybrid nature of the pump creates high efficiencies for high viscous fluids that can contain solids. These will be pumped with much lower power requirements than traditional technologies.





Verderhus® HSBH Close Coupled Pumps

Horizontally orientated close coupled pump mounted on a base plate handling high viscosities and large solids up to large flowrates.

Max. Flow	1500 m³/h	Head max	max 55 mwc



6 VERDERHUS SCREW CENTRIFUGAL PUMPS

Verderhus® HSTA Submersible Pumps

A submersible screw centrifugal pump construction able to handle high viscous and large solids.

The motors conform to an IP68 standard that make them ideal for efficient operation when submerged in the fluid being pumped. These pumps can come with mounting options such as auto-coupling or a suction stand as standard, depending on the application which includes slurry pumping, sewage treatment plants, flocculent transfer, mine dewatering, drainage and many more.

Max. Flow	250 m³/h	Head max	max 30 mwc			
Application areas for both HSBH and HSTA						
→ Wastewater		→ Delicate particles				
_∧ Effluent _		_► Sludge				
→ Brewing → Water wit		Water with activation	ited carbon			
→ Food processing → Storm water						
→ Oils and oily wa	Oils and oily water Fruit and vegetable transpor		ole transport			

Slurries

A PUMP SOLUTION FOR EVERY APPLICATION

Lime slurry (Calcium hydroxide, Ca(OH)2 or Kalkmilch) is used globally to correct waste water pH levels and to neutralize incinerator exhaust emissions.

The process

Lime slurry is used to neutralize incinerator emissions and remove Dioxins and similar hazardous chemicals.

The problem

The existing vortex tank feed pump had to be serviced every month because abrasive wear caused by the lime slurry.

The solution

The Verderhus B close coupled pump has been running for 36 months without any maintenance.

A UK manufacturer required precise blending and gentle handling of lubricant oils, critical to all types of industrial processes.

The process

A 220cPs anti-foaming additive lubricant is transferred between tanks.

The problem

Previously a series of centrifugal pumps, each with a 4kW motor, transferred a 220cPs antifoaming additive lubricant mix between tanks. The viscosity was too high for the closed impeller design requiring an over-sized pump resulting in high-energy costs and frequent planned pumping maintenance cycles.

The solution

An initial Verderhus 80 x 50A pump proved it could pump the lubricant blend whilst drawing only 1.25kW, a 70% power reduction and has resulted in the installation of a further 7 pumps. Pumping Industrial Oils

Pumping Malt

IL ML' 32 KG2

Pumping Lime

A Bavarian Brewery produces malt, an extremely difficult medium to pump.

The process

The malt is pumped at 120-130 m³/h against a head of 10 - 12 mwc.

The problem

The customer previously used a semi-open vortex impeller pump. After the pump was stopped, the

solid content of the malt solution changed resulting in clogging issues on pump restart. This required both the pump and pipe to be opened and to be cleaned.

The solution

An initial Verderhus 150 x 100B close coupled pump was installed, ran without problems and the satisfied customer ordered an additional 4 Verderhus pumps.





VERDER LTD. Unit 3, California Drive Castleford, West Yorkshire, WF10 5QH United Kingdom

MAIL sales@verder.co.uk
WEB www.verder.co.uk

AUSTRIA / BELGIUM / BULGARIA / CHINA / CROATIA / CZECH REPUBLIC GERMANY / DENMARK / FRANCE / HUNGARY / INDIA / ITALY / THE NETHERLANDS / POLAND / ROMANIA / SLOVAKIA / THAILAND / UNITED KINGDOM / USA / SERBIA / SLOVENIA / SOUTH AFRICA / SWITZERLAND