

A Series
Eccentric Disc Pump

Where Innovation Flows

Mouvex A Series Eccentric Disc Pumps have been some of the most reliable pumps available. Since 1965, these workhorse transfer pumps have earned a strong reputation in some of the harshest applications in the world.

Now, these pumps have expanded their capabilities to serve more markets and a wider range of industrial applications and feature flow rates to 55 m³/h (242 gpm).

The Rugged
A Series
Eccentric Disc Pump
Just Got Better

A Series Pumps Now Offer:

- ANSI150 / ISO PN16 Flanges
- Ductile Iron Construction
- Standard or Mouvex Mechanical Seals
- Increased Differential Pressure to 10 bar (145 psi)



The New Improved A Series Eccentric Disc Pump

Robust Design

The Eccentric Disc design of the A Series pump provides exceptional suction capabilities for dry self-priming. Discharge pressure allows for complete line clearing, a consistent benefit that characterizes the unique Mouvex principle.

Legendary Construction with Improved Performance

The A Series pump has long been a rugged workhorse for difficult applications. The self-compensating design allows for constant output over long periods of operation. Now, the A Series has improved on its already durable performance characteristics:

Increased Differential Pressure	To 10 bar (145 psi)
Additional Materials of Construction	Ductile Iron
Versatile Standard Connections	ANSI150 Flanges ISOPN16 Flanges
Enhanced Sealing Options	Mouvex Seals Standard Mechanical Seals



Innovation allows Mouvex to keep pace with today's demanding fluid transfer applications. Whether it is viscous, non-lubricating, volatile or delicate, shear-sensitive materials, the A Series delivers consistent flow rates and pressure.

Model	Size	Max. Flow Rate
A6	1½"	5.7 m³/h (25 gpm)
A12	2"	11.7 m³/h (52 gpm)
A18	2½"	18 m³/h (79 gpm)
A31	3"	31 m³/h (136 gpm)
A55	4"	55 m³/h (242 gpm)

Transfer Applications:

- General Chemical
- Detergents
- Glues & Inks
- Paint & Coatings
- Fuel Oil
- Food Products
- Used Oil
- Bitumen



ZI la Plaine des Isles
2 rue des Caillottes • F-89000 AUXERRE - FRANCE
O: + 33.3.86.49.86.30 • F: + 33.3.86.46.42.10
contact@mouvex.com
www.mouvex.com

See the Mouvex
Principle in Action



Authorized PSG Partner:

VERDER NV
Kontichsesteenweg 17
B-2630 Aartselaar
Belgium

TEL +32 3 877 11 12
FAX +32 3 877 05 75
MAIL info@verder.be
WEB www.verder.be